



Web Administration Interface – User Guide

(version 2.2)

Disclaimer

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR WYDE VOICE REPRESENTATIVE FOR A COPY.

IN NO EVENT SHALL WYDE VOICE OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF WYDE OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Copyright

Except where expressly stated otherwise, the Product is protected by copyright and other laws respecting proprietary rights. Unauthorized reproduction, transfer, and or use can be a criminal, as well as civil, offense under the applicable law.

WYDE Voice and the WYDE Voice logo are registered trademarks of WYDE Voice LLC in the United States of America and other jurisdictions. Unless otherwise provided in this Documentation, marks identified with “R” / ®, “TM” / ™ and “SM” are registered marks; trademarks are the property of their respective owners.

For the most current versions of documentation, go to the WYDE support Web site:
<http://docs.wydevoice.com/>

November 30, 2010

Symbols and Notations in this Manual

The following notations and symbols can be found in this manual.



Denotes any item that requires special attention or care. Damage to the equipment or the operator may result from failure to take note of the noted instructions

Figure	Denotes any illustration
Table	Denotes any table
Text	Denotes any text output
<i>Button</i>	Denotes any button caption

Table of Contents

Symbols and Notations in this Manual	3
Table of Contents	4
Tables List	6
Figures List	7
Chapter 1: Introduction	9
Assumed Skills	9
Architecture Overview	9
Hardware	10
Voice Clients	10
Integration Adapters	10
Definitions	10
Chapter 2: Web Administration Interface	13
Prerequisites	13
Accessing the Web Administration Interface	13
Logging In	14
Components of the Web Administration Interface	14
Subscriber User Management	16
Create a Subscriber	16
View/Modify a Subscriber	18
Delete/Deactivate a Subscriber	20
Create a Conference Account	20
Configuration of the Conferences	22
Modify a Conference Account	23
Delete a Conference Account	25
Conferences and Calls Management	26
Calls	26
View Calls in progress	26
Dropping Call Participants	28
Mute Call Participants	29
Placing Call Participants on Hold	29
Conferences	30
View Conferences in progress	30
Conference Mute and Q&A Modes	32
Q&A Sessions	33
Dropping a Conference	34
Making a Conference Secure	34
Placing a Conference on Hold	36
Active Speaker Notification (ASN) mode	38
Automatic Gain Control	39
Recording a Call	40
Dialing Another User	41
Polling	42
Scheduling	44
Maintaining Conferences Maximal Duration	47

Operator Conferences	49
Control Operator Conferences Using Touch Tone Commands.....	50
Control Operator Conferences Using Web Administration Interface	51
Samples and Use-Cases of Operator Conference Procedures	54
Web Report Management.....	55
Running a report	58
Report Screenshots	58
DNIS Management	64
View Existing DNIS Associations	64
Create a DNIS Association.....	65
Modify an Existing DNIS Association's Attributes	66
Remove a DNIS Association.....	67
System Management	69
Change System Preferences	69
Chapter 3: Call Flows	71
Call Flow Attributes	73
CONF	80
Sample of Conference Call Procedures Using the CONF Call Flow	82
Entering conference call as a Host	83
Entering a conference call as a Participants	83
Question and Answer Sessions within Conference Calls.....	83
OPERATOR.....	84
PLAYBACK.....	85
Recording and Playing Back a Conference	86
Recording Instructions.....	87
Play Back Instructions	87
SPECTEL	87
Sample of Conference Call Procedures Using the SPECTEL Call Flow.....	90
Entering conference call as a Host	90
Entering a conference call as a Participants	90
Appendix A: Support Resources	92
Support Documentation.....	92
Web Support.....	92
Telephone Support.....	92
Email Support.....	92

Tables List

Table 1: Web Administration Menus and their Administration Areas.....	15
Table 2: Calls Columns	26
Table 3: Conference Call Columns	27
Table 4: Conference View Columns	31
Table 5: Operator Commands for OPERATOR Call Flow Conferences.....	50
Table 6: Calls Report Columns	56
Table 7: Conferences Report Columns.....	56
Table 8: DNIS Report Columns	58
Table 9: Call Flow Attributes	74
Table 10: CONF Call Flow Attributes	81
Table 11: Host Commands for CONF Call Flow Conferences.....	83
Table 12: Participant Commands for CONF Call Flow Conferences	83
Table 13: OPERATOR Call Flow Attributes.....	84
Table 14: PLAYBACK Call Flow Attributes	86
Table 15: Recorded Conference Call Playback Touch Tone Commands	87
Table 16: SPECTEL Call Flow Attributes	87
Table 17: Host Commands for SPECTEL Call Flow Conferences.....	90
Table 18: Participant Commands for SPECTEL Call Flow Conferences.....	91

Figures List

Figure 1: The WYDE Bridge Architecture	9
Figure 2: Initial Web Administration Login Screen	14
Figure 3: Components of the WYDE Web Administration Interface	15
Figure 4: Subscribers Menu	16
Figure 5: Creating a New Subscriber	17
Figure 6: View System Subscribers	18
Figure 7: Viewing Subscriber Information	20
Figure 8: Creating a New Conference Account	21
Figure 9: The Conference Account Created	22
Figure 10: Sample of User Roles Configuration for the Conference	23
Figure 11: Modifying a Conference Accounts	24
Figure 12: View Calls Information	27
Figure 13: Viewing the Callers within a Conference	28
Figure 14: The Location of the Mute Call Participants Checkbox	29
Figure 15: The Location of the Hold Call Participants Checkbox	30
Figure 16: View Conference Information	31
Figure 17: The Location of the Conference Mode Dropdown	32
Figure 18: The Location of the Q&A Conference Icons	34
Figure 19: The Location of the Secure Conference Link	35
Figure 20: The Location of the Secure Conference Checkbox	36
Figure 21: The Location of the Hold Conference Link	37
Figure 22: The Location of the Hold Conference Checkbox	38
Figure 23: The Location of the Active Speaker Notification (ASN) Conference Link	39
Figure 24: The Location of the Automatic Gain Controls (AGC) and the Gain Control Window	40
Figure 25: The Sample of the Different Gain Controls	40
Figure 26: The Location of the Recording Conference Link	41
Figure 27: Dialing Out to Another User	42
Figure 28: The Location of the Polling Conference Link	43
Figure 29: The Conference Polling Session Voting Charts	44
Figure 30: Scheduling Call Flow Attributes Sample	45
Figure 31: Sample Conference Screen when OPERATOR conference is in progress	49
Figure 32: View Conference Information when OPERATOR conference is in progress	51
Figure 33: Viewing the Callers within an OPERATOR Conference, the user is in an operator queue	52
Figure 34: Viewing the Callers within an OPERATOR Conference, the user is speaking with an operator	52
Figure 35: Attach User to a Different Conference	53
Figure 36: Main Reports Window	55
Figure 37: Calendar to Select either the "From" Date or the "To" Date	55
Figure 38: Sample Calls report	59
Figure 39: Sample Conferences Report	59
Figure 40: Sample Gantt Chart for the Conference	60
Figure 41: Sample File Manager for the Conference	60
Figure 42: Sample DNIS Report	61

Figure 43: Sample Load Chart	61
Figure 44: Sample Show SW report	62
Figure 45: Sample Show Stat Report	62
Figure 46: Sample Show Boards Report	63
Figure 47: Viewing Existing DNIS Associations and Call Flows.....	65
Figure 48: Creating a New DNIS Association	66
Figure 49: Modify an Existing DNIS Association	67
Figure 50: DNIS Association Deletion Confirmation Dialog	68
Figure 51: Changing System Preferences.....	69
Figure 52: Modifying CONF Call Flow Attributes.....	73
Figure 53: Modifying PLAYBACK Call Flow Attributes	86

Chapter 1: Introduction

This is the Administration guide for the WYDE conferencing bridges (like SB 1000, VM 1000, and VM 3000). Within this guide you will learn how to perform the basic day to day administration tasks for these units.

Assumed Skills

This administration guide assumes you have a working knowledge of the following technologies and skills:

- PC usage
- System administration
- VOIP basics
- TCP/IP networking

Architecture Overview

The WYDE architecture is made up of both hardware as well as software services (as shown in Figure 1) that work together to provide the best carrier-class, wideband conferencing available.




Figure 1: The WYDE Bridge Architecture

WYDE services is not only turnkey software solution, it is the component that can be easily integrated into other products. The WYDE Bridge can be controlled either using web services or using real-time interface. Web services send requests to the bridge and receive information about status of the bridge. The real time interface makes call to the bridge using special client, perform SIP call to send and receive commands and exchange information about the conferences.

Hardware

There are three primary WYDE platforms – the SB 1000, the VM 1000 and the VM 3000. They are designed to be attached to your network in appliance-fashion. They are, for all intents and purposes, servers that can be installed and managed as such.

For more information on the WYDE hardware and its specifications – please visit www.wydevoice.com.

Voice Clients

There are three possible clients for WYDE bridge: soft phones, IP phones, and regular (PSTN) telephones. The most famous soft phones are Counterpath X-Lite, Flaphone, SJ Labs SJphone; also you can use Skype as your soft phone. The most famous manufacturers of IP phones are Audio Codes (with Audio Codes 320HD), Polycom HD Voice (with Polycom 550HD), and Snom (with Snom 320). In case of the regular telephone – there is a need to have a separate unit – a voice over IP gateway in order to use the phones, for example Cisco AS 5400 or similar.

Integration Adapters

WYDE can be integrated into an enterprise infrastructure through the set of adapters. There are three points of integration:

- **CDR storage** – A storage location for the individual call records. This can be SQL database or something else.
- **Authentication service** – This allows the WYDE software to integrate into the enterprise authentication systems. This could be a SQL database, RADIUS, LDAP, or other.
- **Call/Conference management** – This is the ability to manage conference calls, exposed through the Web API for integration with enterprise web sites.

Definitions

In order to discuss the WYDE bridge effectively, we need to have a common set of terminology. For this purpose, we should define the dictionary for the terms you will see throughout this administration guide:

- **Subscriber** – A real person, he has a name, phone number, e-mail address, etc. The subscriber can have conference accounts, he does not have access codes, but access codes are properties of conference accounts that have subscribers. Note that non-admin (non-operator) subscribers can see only “own” information, i.e. his information and information that belongs to subscribers created by him, he can see only their calls, conferences, the reports will show only their data, etc.

- **PIN** – The login ID for the subscriber (must be unique). It can be used either as login in Web Administration Interface (in this case it can be either number or alpha-numeric) or as login for some call flows (in this case must be numeric) for participants authorization.
- **Conference Account** – The element of subscriber conferences configuration. Conference accounts always belong to subscriber. It is being used to define a person in a conference with a particular role (e.g. host, participant, listener, etc.), the DNIS number that should be used to call to the conference, and the access code that should be entered by the user that called to the conference DNIS to determine his role. A subscriber could be a host user in one conference and a listener in another. Conference accounts with the same conference number represent single conference setup.
- **DNIS** – A unique set of numbers that is outputted by a phone carrier that indicates the intended destination for a particular call. It can be any length digits (although usually 10 digits). DNIS is the property of the conference account, but different DNIS numbers can be used to connect to the same conference.
- **Access Code** – A numeric code unique for DNIS that allows a host or participant or listener access to a conference call. When users call to DNIS number they being asked to enter their access code. The access code determines the conference and the user role in the conference. Different access codes can determine the same conference, for instance one access code can determine the connected user has host role, another access code can determine that connected user has participant role, and another access code can determine that connected user has listener role.
- **Host** – A user in the conference call that can make changes to the system while the conference call is in progress. Like change the security setting, change who can talk or answer, etc. Sometimes the host user is called moderator. This user role is defined in conference account.
- **Participant** – A person in the conference who can actively participate in a call by both talking and listening. This user role is defined in conference account.
- **Listener** – A person in the conference who can hear the conference call, but cannot speak. Their audio path is one way only (receive). This user role is defined in conference account.
- **Conference Number** – A unique external conference number. Conference number is the property of conference account. If the conference accounts have the same conference number all these accounts determine one single conference. For instance the user can create one conference account record that determine host role, another conference account record that determine participant role, and another conference account record that determine listener role – all these records should have the same conference number to determine one unique conference.
- **Conference ID** – A unique conference ID that represents the instance of a conference. When any conference is being started it receives unique conference ID, and all calls to this conference have the same conference ID; if this conference has been completed and another conference is being started that conference will receive another conference ID. Conference ID is normally not exposed to users, unless on the reports.
- **Call Flow** – A unique conference service setup, the logic that is used to process the conference calls. This is the process a call goes through from call setup to, to processing, to call tear down. It includes the logic, DTMF key-presses used, functions,

and the recorded prompts. There are two basic call flow categories: call flows without authentication (like CONF call flow) and call flows with authentication (like SPECTEL call flow).

- **Audio Key** – A key sequence that is used to group different calls from the same conference in a bundle to manage these calls using real-time or another external interface. Audio key is being generated by real-time application, for instance Moderator-Console, the user can enter the same audio key on his DTMF keypad, usually as #audio key# or #9audio key#, these calls (the call from real-time application and the user call to the conference) are being grouped together and the real-time application can manage this user call (the call with the same audio key), for instance mute the call, etc.

Chapter 2: Web Administration Interface

The WYDE Web Administration Interface allows an administrator to make changes and administrate the operation of the system of the WYDE conference bridges.

The WYDE Web Administration Interface is included with the WYDE conference bridges to make everyday administration easier. You can use it to manage users/subscribers, manage conferences and individual calls, as well as run reports and change DNIS information for various types of calls. It is a simple tool that makes administration easier.

As subscriber management you can create/modify/delete them – manage their PIN, passwords, modify subscriber attributes, such as first and last names, email, telephone. In addition you can create/modify/delete subscribers' conference accounts – define their conferences, used DNISes and access codes.

As conference management you can manage the conferences and calls that currently are in progress, you can view started conferences and calls, as well as set and change some of their modes – mute the conferences and participants, placing the call on hold, making the call secure, record the call, etc.

The reports are used to get different information and statistics from the bridges – you can see inbound and outbound calls processed by the system, the conferences that have taken place, the usage of each DNIS and how many calls processed on each DNIS (including outbound calls), call traffic statistics by time of day, load utilization, etc. The reports can be used to troubleshoot the problems and planning your actions.

As DNIS management you can create/modify/delete DNIS associations of the actual inbound DNIS numbers and call flows that are used to service these numbers. In addition the web interface allows you to change system preferences.

Prerequisites

You may use to access the internal Web administration interface to administer various components of the WYDE system. Before you do, however, you must have the following prerequisites met:

- A computer with a network connection to the TCP/IP subnet where the WYDE appliance is connected
- A supported web browser (Mozilla FireFox 1.0 and above or Internet Explorer 7.0 and above) installed

Accessing the Web Administration Interface

To access the web administration interface, use the following procedure:

Open your web browser.

1. In the address bar, type in the assigned IP address of your WYDE system (the address where the DNCA services are running)
2. You should see a screen similar to the one in Figure 2. If you do not, check that are using the proper IP address and that the DNCA services are running.



The image shows the initial login screen of the Web Administration Interface. At the top left is the WYDE VOICE logo. At the top right, it says "24/7 Professional Customer Service" and "TOLL FREE 866.508.9020". Below this is a black bar with the text "CONFERENCE APPLIANCE MANAGER". The main content area has a login form with two input fields: "PIN:" and "Password:". Below the fields is a "LOGIN" button. At the bottom, there is a link: "Problems logging in? Contact Support at support@wydevoice.com".

Figure 2: Initial Web Administration Login Screen

Logging In

Once you receive the login screen, use your default PIN (admin) and default password (admin) to log in to the web administration interface. Type in your PIN/Password in the labeled fields and click “Login”. If successful, you will be presented to the administration interface, as shown in the next section. Remember the usernames and passwords are case sensitive.

Components of the Web Administration Interface

The administration interface consists of three main components, as shown in Figure 3. These components are:

- **Menu Bar:** This area contains the general administration areas of the Web Administration tool. Table 1 outlines these areas and the types of information that can be administered under each menu
- **Admin Area:** This is the area where the actual administration occurs. It changes based on the item selected in the menu bar and the subsequent action being performed
- **Action Buttons:** These buttons are green by default and usually initiate some kind of action, such as search, create, delete, update, or cancel.

WYDE VOICE 24/7 Professional Customer Service TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Keyword: First Name

List records: 1/10 << Previous 1 Next >>

Subscriber Name	Role	PIN	Authorized by	Phone Number	Email
<input type="checkbox"/> Baringer George		gbaringer	administrator		gbaringer@readmail.net
<input type="checkbox"/> Caballero Rogelio		179067	administrator	(278) 329-6118	Rogelio.Caballero@mail.com
<input type="checkbox"/> Kraft Julie		jkraft	administrator	(204) 221-7600	jkraft@phone-mobile.com
<input type="checkbox"/> Kramer Francis		619346	administrator		
<input type="checkbox"/> Morrison Matt		139512	administrator	(325) 684-8417	mm@abc-mail.com
<input type="checkbox"/> Noble Robert		robert	administrator	(885) 438-0566	rnoble@rbc.com
<input type="checkbox"/> North Perry		415747	administrator	(328) 879-2583	pnorth@north.org
<input type="checkbox"/> Painchaud Regis		regis	administrator	(335) 876-2294	regis@hotmail.com
<input type="checkbox"/> Small Anthony		administrator		(555) 266-3056	small@manage.com
<input type="checkbox"/> Tobias Mel		MelTobias	administrator	(507) 731-4500	

ADMIN AREA

MENU BAR **ACTION BUTTONS**

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 3: Components of the WYDE Web Administration Interface

Table 1: Web Administration Menus and their Administration Areas

Menu	Description
Subscribers	Allows you to add, delete, and modify subscribers as well as their own conferences
Conferences	Allows you to delete and manage active conferences
Calls	Allows you to view current calls in progress, both inbound and outbound
Reports	Allows you to view reports on all calls and conferences that have taken place
DNIS	Allows you to modify how inbound calls are routed to different call flows
Preferences	Allows you to change the hostname, number of simultaneous calls, and number of rows shown in the admin area
Logout	When selected, will log you out of the web administration interface

Now that you have successfully logged in to the administration interface, you can begin administering the system using whichever interface you choose.

Subscriber User Management

One of the administration tasks that you will be called upon frequently to do is to add unique subscribers to the system and allow them to use the system. For terminology's sake we should clarify one main terminology item. A subscriber is a real person – he has a name, phone number, e-mail address, etc. A user is a person in a conference with a particular role (e.g. host, participant, listener, etc). So a subscriber could be a host user in one conference and a listener in another and a subscriber can have different roles in the same the conferences.

Note. Operator is unable to playback the recorded conferences via Reporting of Web Administration Interface.

Create a Subscriber

Whenever a new person needs access to the system, you must create a new subscriber for them so that they can log in to the system.

To create a subscriber using the web interface, use the following steps:

1. Log in to the web interface
2. Open the Subscriber Management section of the portal by clicking the “Subscribers” menu. The screen should look similar to Figure 4.

The screenshot shows the Wyde Voice web administration interface. At the top, there is a logo for "WYDE VOICE" and a contact number "24/7 Professional Customer Service TOLL FREE 866.508.9020". Below this is a navigation bar with links: "Subscribers", "Conferences", "Calls", "Reports", "Preferences", and "Logout". The "Subscribers" link is highlighted. To the right of the navigation bar is the text "CONFERENCE APPLIANCE MANAGER". Below the navigation bar is a search section with a "Keyword:" label, a text input field, a "First Name" dropdown menu, a "Search" button, and a "Create Subscriber" button. Below the search section is a table of subscribers. The table has columns: "Subscriber Name", "Role", "PIN", "Authorized by", "Phone Number", and "Email". The table contains 10 rows of subscriber data. At the bottom of the page, there is a footer with the text "FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2008-2009 Wyde Voice, All Rights Reserved."

Subscriber Name	Role	PIN	Authorized by	Phone Number	Email
Baringer George		gbaringer	administrator		gbaringer@readmail.net
Caballero Rogelio		179067	administrator	(278) 329-6118	Rogelio.Caballero@mail.com
Kraft Julie		jkraft	administrator	(204) 221-7600	jkraft@phone-mobile.com
Kramer Francis		619346	administrator		
Morrison Matt		139512	administrator	(325) 684-8417	mm@abc-mail.com
Noble Robert		robert	administrator	(885) 438-0566	rnoble@rbc.com
North Perry		415747	administrator	(328) 879-2583	pnorth@north.org
Painchaud Regis		regis	administrator	(335) 876-2294	regis@hotmail.com
Small Anthony		administrator		(555) 266-3056	small@manage.com
Tobias Mel		MelTobias	administrator	(507) 731-4500	

Figure 4: Subscribers Menu

3. Click the “*Create Subscriber*” button to start the subscriber creation process.
4. In the screen that appears (similar to Figure 5), fill out the information for the new subscriber. The fields that are required are noted with an asterisk (*). The fields you need to fill out include:
 - **PIN:** Essentially the login ID for the subscriber – It is usually a number so this PIN can be used as a login id by telephone for additional conference features to identify the subscriber, if this is determined by call flow. This login also can be used as login into this Web Administration Interface. If the login is planning to be used as web login only, the PIN can be alpha-numeric.
If you don’t want to come up with your own numbering scheme for logins, you can click the “*Generate*” button to generate a random, unique ID for the new subscriber.
 - **Password:** This is a password for the user, that is used to login into Web Administration Interface. Note: you must type the password twice – once in the “Password” field and again in the “Confirm Password” field to ensure you typed it correctly.
 - **First Name:** The subscriber’s first name.
 - **Last Name:** The subscriber’s last name.
 - **Email:** The email address of the subscriber.
 - **Telephone No:** The primary telephone number of the subscriber. This phone number can be used during conference call setup for callout to the subscriber.
 - **Grant operator permission:** When checked – the subscriber will be able to see all other subscribers and their conferences and calls; when unchecked – the subscriber will be able to see only own (subordinate) subscribers and their conferences and calls.

WYDE VOICE 24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Personal Information

*PIN: 839194

*First Name: Andrew

*Last Name: Merrill

*Password:

Email: amerrill@infomail.com

*Confirm Password:

Telephone No: (878) 737-1432

Grant operator permission ☐

*The field is mandatory

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 5: Creating a New Subscriber

5. Click the “*Create*” button to create the new subscriber.
6. Once the subscriber is created, a window will pop up indicating that it is “Now creating conference accounts ...”. This means it is going to create conference account for the

new subscriber. If you click “OK” you will be taken to the page so you can create a conference account (covered in later in this chapter). If you don’t want to create a conference account for this new subscriber, you can click “Cancel” and you will be returned to the main subscriber menu.

7. In the subscribers menu, you should now see your new subscriber (as shown in Figure 6). You should also be able to use this subscriber to log in to the web interface. Notice the “Authorized By” column. This column indicates the user who created that subscriber (also known as the “Parent” of that subscriber). If the subscriber has operator permissions (the “Grant operator permission” checkbox is checked for him) he is able to see all subscribers that exist in the system. If the subscriber does not have operator permissions he is able to see only own sub-subscribers, in other words he is able to see himself and the subscribers authorized by him.

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Keyword: First Name Search

List records: 1/11 << Previous | 1 | Next >>

Subscriber Name ▲	Role	PIN	Authorized by	Phone Number	Email
✕ Baringer George		gbaringer	administrator		gbaringer@readmail.net
✕ Caballero Rogelio		179067	administrator	(278) 329-6118	Rogelio.Caballero@mail.com
✕ Kraft Julie		jkraft	administrator	(204) 221-7600	jkraft@phone-mobile.com
✕ Kramer Francis		619346	administrator		
✕ Merrill Andrew		839194	administrator	(878) 737-1432	amerrill@infomail.com
✕ Morrison Matt		139512	administrator	(325) 684-8417	mm@abc-mail.com
✕ Noble Robert		robert	administrator	(885) 438-0566	rnoble@rbc.com
✕ North Perry		415747	administrator	(328) 879-2583	pnorth@north.org
✕ Painchaud Regis		regis	administrator	(335) 876-2294	regis@hotmail.com
✕ Small Anthony		administrator	administrator	(555) 266-3056	small@manage.com
✕ Tobias Mel		MelTobias	administrator	(507) 731-4500	

New Subscriber Created

The user who created that subscriber

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 6: View System Subscribers
(subscriber menu after adding a new subscriber)

View/Modify a Subscriber

Sometimes administrators need to make changes to existing subscribers. The WYDE services have several ways of viewing and/or modifying existing subscribers.

You can use the web interface to view and modify any existing system subscribers and their information. To view existing subscribers and their information, log in to the web interface and click on the “Subscribers” menu. You will see a screen similar to Figure 6. This shows

all the current subscribers on the system. If you wish to sort this list, click on the column heading of the column you wish to sort by (the default is sorted ascending by subscriber name). To reverse any sort order, click the column heading again.

Also, since there may be more than one page of subscribers, you'll notice a navigation bar under the "Create Subscriber" button that looks like the following:

List records: 1/168 << Previous | [1](#) [2](#) [3](#) ... | [Next >>](#)

This bar allows you to navigate amongst the different pages of subscribers. You can click on the "Next >>" to move to the next page of subscribers, or the "<< Previous" to move to the previous page. Or, you can click on any number to go to that numbered page.

In addition you can search the subscribers based on First Name, Last Name, PIN, Email, Phone Number, Access Code, Conference Number, DNIS:

Keyword:

Note. You can use the same sorting, navigation, and search mechanism on any other screens, such as "Conferences", "Calls", "Reports", "DNIS".

To view and change the details of any subscriber using the web interface, log in to the web interface and use the following procedure:

1. Click on the "Subscribers" menu to view the list of subscribers on the system
2. Locate the subscriber whose details you wish to view or modify.
3. Click on that subscribers' Subscriber Name (each subscriber name is highlighted as a link) to bring up the subscriber property page (Figure 7) for that subscriber.

WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Personal Information

*PIN: 839194 [Generate]

*First Name: Andrew

*Last Name: Merrill

*Password: [Masked]

Email: amerrill@infomail.com

*Confirm Password: [Masked]

Telephone No: (878) 737-1432

Grant operator permission ☐

[Update] [Cancel]

*The field is mandatory

Conference Accounts

[Create]

List records: 1/-1 << Previous | 1 | Next >>

Conference Number	DNIS	Access Code	Role
-------------------	------	-------------	------


Figure 7: Viewing Subscriber Information

4. You can modify any of these fields simply by clicking in the appropriate field, typing the new text, then clicking the “Update” button.

Delete/Deactivate a Subscriber

From time to time, you will need to delete a subscriber.

To delete a subscriber using the web interface, log in to the web interface and use the following procedure:

1. Click the “Subscribers” menu to view the list of subscribers on the system.
2. Locate the subscriber you wish to delete.
3. Click the  button next to the subscriber you wish to delete. The interface will prompt you with “Are you sure you want to Delete?”. If you click “OK” the subscriber will be deleted.

Create a Conference Account

A conference account is essentially a set of configuration settings for a particular subscriber for a particular DNIS/Call flow. Within a conference account configuration, each given a unique ID#, you specify how a particular subscriber will interact – whether they will be host, participant, or listener, which DNIS/Call flow will be used, and what the access code will be for that conference account will be.

To create a conference with the web interface, start by logging in to the web interface and locating the subscriber you wish to create the conference for. Then, use the following procedure to create it:

1. Click on the Subscriber Name of the subscriber you wish to create a conference for to view their details (Figure 7).
2. Click the “Create” button to start the creation process. A new window will appear (Figure 8).

The screenshot shows the Wyde Voice web interface. At the top left is the Wyde Voice logo. At the top right, it says "24/7 Professional Customer Service" and "TOLL FREE 866.508.9020". Below this is a navigation bar with links: "Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout |" and "CONFERENCE APPLIANCE MANAGER". The main form is titled "Create" and contains the following fields:

- *Conference Number: 402295 (with a "Generate" button)
- *Dnis: 10 - CONF (dropdown menu)
- *Access Code: 460440 (with a "Generate" button)
- *Role: Host (dropdown menu)

At the bottom of the form are "Create" and "Cancel" buttons. A red asterisk note below the form states: "*The field is mandatory". At the very bottom, a small copyright notice reads: "FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved."

Figure 8: Creating a New Conference Account

3. Enter the conference number that should be used to access this conference. You can either enter your own number, or use the automatically generated number that comes up by default, or generate a new conference number by clicking the “Generate” button.
4. Choose the DNIS for this conference. A DNIS is used to uniquely identify which number and which call flow should handle the incoming call.
5. Enter the access code that should be used to access this conference. The access code should be unique within DNIS. All participants will use this access code to gain access to this conference. You can either enter your own number, or use the automatically generated number that comes up by default, or generate a new access code by clicking the “Generate” button.
6. Choose the role that the subscriber will play in this conference. A subscriber can be any one of three options (which can be selected by choosing the appropriate option from the drop down list)
 - a. **Host** – A host is the user in the conference call that can make changes to the system while the conference call is in progress. Like change the security setting, change who can talk or answer, etc.
 - b. **Participant** – A participant can actively participate in a call by both talking and listening.
 - c. **Listener** – A listener can hear the conference call, but cannot speak. Their audio path is one way only (receive).
7. Click the “Create” button to create the new conference. The conference will now appear in the property page of that user (Figure 9).

WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

[Subscribers](#) | [Conferences](#) | [Calls](#) | [Reports](#) | [DNIS](#) | [Preferences](#) | [Logout](#) | **CONFERENCE APPLIANCE MANAGER**

Personal Information

*PIN:

*Password:

*Confirm Password:

Grant operator permission ☐

*First Name:

*Last Name:

Email:

Telephone No:

*The field is mandatory

New Conference Account Created

Conference Accounts

List records: 1/-1 << Previous | 1 | Next >

Conference Number	DNIS	Access Code	Role
402295	10 - CONF	460440	host

Figure 9: The Conference Account Created

Configuration of the Conferences

Note that there could be different approaches with conferences configuration and setting access codes and roles for the conferences. If you would like to configure the single conference, the conference number must be the same in all conference accounts records that describe this single conference. However the DNIS number and/or subscriber for them could be different; the way that the system determines that it is the single conference is that it has same conference number.

The first approach to configure the conference is the following: the subscriber creates for himself the conference account records with the same conference number (this determines that it is the single conference configuration) and multiple records with different access codes that are used for different roles (Figure 10). Depending on what access code is used when the user has entered in the conference, the role of this user is different, and the user can be either the host, or the participant or the listener.

WYDE VOICE 24/7 Professional Customer Service TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Personal Information

*PIN: 839194 [Generate]

*Password: [Masked]

*Confirm Password: [Masked]

Grant operator permission ☐

*First Name: Andrew

*Last Name: Merrill

Email: amerrill@infomail.com

Telephone No: (878) 737-1432

[Update] [Cancel]

*The field is mandatory

Conference Accounts

Single conference

Different roles for the same conference depending on access codes used

Conference Number	DNIS	Access Code	Role
402295	10 - CONF	460440	host
402295	10 - CONF	981610	participant
402295	10 - CONF	921193	listener

Figure 10: Sample of User Roles Configuration for the Conference

The second approach to configure the conference is creating conference accounts for each subscriber that should participate in the conference. The conference number for all these conference accounts must be the same, and these records will show what access code should use the subscriber and subscriber role in the conference call.


Modify a Conference Account

Once you have a conference account created, you may need to change it.

To modify a conference account, you may think that you could go to the “Conferences” menu and just select the conference and change it. However, conference account settings are particular to a particular subscriber, and the “Conferences” menu is only conferences that are currently in use.

To modify a conference account using the web interface, log in to the web interface and navigate to the user whose conference account you wish to modify. The conference accounts are listed on their property page. To view and modify the details of any of these conference accounts, follow this procedure:

1. Click on the Conference Number of the conference you wish to modify. A screen similar to the one shown in Figure 11.



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout |
CONFERENCE APPLIANCE MANAGER

*Conference Number: Generate

*Dnis:

*Access Code: Generate

*Role:

Update
Cancel

*The field is mandatory

Description	Name ▲	Value	Overridden
call			
Announce participant count on enter	call_announceparticipantcount	<input type="text" value="hp"/>	<input type="checkbox"/>
Exit DTMF policy	call_exit_dtmf	<input type="text" value="hpl"/>	<input type="checkbox"/>
Instructions DTMF policy	call_instructions_dtmf	<input type="text" value="hp"/>	<input type="checkbox"/>
Mute self DTMF policy	call_mute_dtmf	<input type="text" value="hp"/>	<input type="checkbox"/>
Call for Operator DTMF policy	call_operator_dtmf	<input type="text"/>	<input type="checkbox"/>
Tell number of participants during the conference DTMF policy	call_participantsnumber_dtmf	<input type="text" value="hp"/>	<input type="checkbox"/>
conference			
Entry and exit tones DTMF policy	conference_entryexittones_dtmf	<input type="text" value="h"/>	<input type="checkbox"/>
Entry tones	conference_entrytones	<input type="text" value="on"/>	<input type="checkbox"/>
Exit tones	conference_exittones	<input type="text" value="on"/>	<input type="checkbox"/>
Lock conference DTMF policy	conference_lock_dtmf	<input type="text" value="h"/>	<input type="checkbox"/>
Max number of calls per conference	conference_maxcalls	<input type="text" value="-1"/>	<input type="checkbox"/>
Music on hold	conference_moh	<input type="text" value="MP:beep"/>	<input type="checkbox"/>
Mute mode DTMF policy	conference_mute_dtmf	<input type="text" value="h"/>	<input type="checkbox"/>
Q&A session DTMF policy	conference_qa_dtmf	<input type="text"/>	<input type="checkbox"/>
How conference ends	conference_stop_how	<input type="text" value="last"/>	<input type="checkbox"/>
Wait before disconnect when moderator left the conference	conference_stop_wait	<input type="text" value="0"/>	<input type="checkbox"/>


Figure 11: Modifying a Conference Accounts

2. You may change any of the properties of the conference from this screen, just as you did when you created it. Simply modify the entry in any text box (including access code or creating a new conference name) or select a new option from one of the drop down lists.
3. In addition you can override any of default call flow parameters for the conference in the lower section of the screen as shown on Figure 11 (lower section of the screen). If you would like to change any of the parameters, the Overridden checkbox should be checked – otherwise the value you entered will not be saved. The list of available parameters depends on selected DNIS.

Note: you can override call flow parameters only if you select conference account record with the host role; for the participant and the listener roles you are unable to override call flow parameters.

4. Click the “*Update*” button to save the changes.

Delete a Conference Account

If you wish to delete any conference account, simply locate the user whose conference you wish to delete, view the details of the user to show their conference accounts, and then click the  button next to the conference you wish to delete. The interface will confirm by asking “Are you sure?”. Click “OK” to delete the conference or “Cancel” to cancel deletion.

Conferences and Calls Management

Once a conference has begun, you can manage it using the built-in web tools. You can manage conferences on-the-fly using the web interface (although some of the information can be viewed through asterisk built-in tools, as discussed later).

Calls


View Calls in progress

Any time when there are any calls in progress on the bridge, you can view them in the web interface by clicking on “Calls” menu. However, when no calls are in progress, the “Calls” tabs of the web interface will show no data.

1. Click “Calls” menu to view all calls that currently are in process on the bridge (Figure 12). All conferences will be listed, sorted ascending by conference number. There are several columns of information about each call. Table 2 details what each column indicates.

Note, you will see all calls that currently are in process on the bridge only if you login as administrator or the subscriber with operator permissions (see section: Subscriber User Management). If you login as non-operator subscriber you will see only the calls that belong to the conference of your and subordinate subscribers.

Table 2: Calls Columns

Column	Description
 Calling Number	Drop the user call The incoming phone number, i.e. the phone number from which the call was made
Called Number	The DNIS number called
User Name	The name assigned to this particular caller. You can edit it by clicking in this box and typing a new name
Access Code	The access code used to enter the conference
Conference Number	The unique number assigned to each conference
Call Begin	Time when the particular call was placed
Duration	How long the call has been part of the conference
Status	Status of the call
Role	The subscriber’s role for this conference
Mute	Whether or not the user is muted
Hold	Whether or not the user is on hold

The screenshot shows the 'CONFERENCE APPLIANCE MANAGER' interface. At the top, there's a navigation bar with links: Subscribers, Conferences, Calls, Reports, DNIS, Preferences, and Logout. Below this is a search bar with 'Keyword:' and 'First Name' dropdowns, a 'Search' button, and a 'Number of calls: 19' indicator. A 'Set refresh' dropdown is set to 'No Refresh'. On the right, it says 'List records: 1/19 << Previous | 1 | Next >>'. The main table has columns: Calling Number, Called Number, User Name, Access Code, Conference Number, Call Begin, Duration, Status, Role, Mute, and Hold. The table lists 20 entries, including calls from (202) 333-0505, misha, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, and a Moderator-Console entry. Each entry has a delete icon (X) and a status icon (green circle with a checkmark).

Calling Number	Called Number	User Name	Access Code	Conference Number	Call Begin	Duration	Status	Role	Mute	Hold
(202) 333-0505	(347) 767-4197	EVK-host	101156	133205	05:00:20	00m:48s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
(202) 333-0505	(347) 767-4197	EVK-host	101155	133205	05:00:03	01m:05s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
misha	12	Michael Zilbe	11234	667789	05:00:30	00m:38s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
111	(347) 767-4197	John Smith	711233	667788	04:47:19	13m:49s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
111	(347) 767-4197		731233	667788	04:47:17	13m:51s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
112	(347) 767-4197		711234	667789	04:47:20	13m:48s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
112	(347) 767-4197		731233	667788	04:47:17	13m:51s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
113	(347) 767-4197	Andrew Merrill	711235	667790	04:47:20	13m:48s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
113	(347) 767-4197		731234	667789	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
114	(347) 767-4197		711236	667791	04:47:20	13m:48s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
114	(347) 767-4197		731234	667789	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
115	(347) 767-4197		711237	667792	04:47:20	13m:48s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>
115	(347) 767-4197		731235	667790	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
116	(347) 767-4197		731235	667790	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
117	(347) 767-4197		731236	667791	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
118	(347) 767-4197		731236	667791	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
119	(347) 767-4197		731237	667792	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
120	(347) 767-4197		731237	667792	04:47:18	13m:50s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>
Moderator-Console	(347) 767-4197	33	101155	133205	05:00:19	00m:49s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>

FCC-CA ver. 2.0.6 ws ver. 2.0.2 @2006-2009 Wyde Voice, All Rights Reserved.

Figure 12: View Calls Information


- Also you can view the calls that belong to one single conference only. To do that click “Conferences” menu to view the conferences that are in progress (this will be described later in the section View Conferences in progress, Figure 17), and then click the conference number of the conference you wish to view. This will bring up the calls window that shows the individual calls that make up this conference (Figure 13). Table 3 lists a description for each of the columns in this view.

Note that when you are viewing the calls that belong to one single conference in the upper section of the screen you will see additional controls that allow you to manage the conference and all calls that belong to this conference. These controls will be described later in the section Conferences.

Table 3: Conference Call Columns

Column	Description
	Delete a user from this conference
Calling Number	The incoming phone number, i.e. the phone number from which the call was made
Called Number	The DNIS number called
User Name	The name assigned to this particular caller. You can edit it by clicking in this box and typing a new name
Access Code	The access code used to enter the conference

Call Begin	Time when the particular call was placed
Duration	How long the call has been part of the conference
Status	Status of the call
Role	The subscriber's role for this conference
Mute	Whether or not the user is muted
Hold	Whether or not the user is on hold
Q&A	Whether or not the user is asking a question (note, this column is available when you view conference calls only and not available when you view all calls on the bridge)



24/7 Professional Customer Service
TOLL FREE 866.508.9020

[Subscribers](#) | [Conferences](#) | [Calls](#) | [Reports](#) | [DNIS](#) | [Preferences](#) | [Logout](#) | **CONFERENCE APPLIANCE MANAGER**

Conference # 106149

secure : OFF | hold : OFF | ASN : OFF | recording : OFF

Keyword:
Number of calls: 2 Set refresh :

List records: 1/2 << Previous | 1 | Next >>

Calling Number ▲	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
✖ Moderator-Console	(951) 262-1256	<input type="text"/>	931174	20:06:14	472m:05s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
✖ Moderator-Console	(951) 262-1256	<input type="text"/>	931174	20:02:35	475m:44s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	


FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 13: Viewing the Callers within a Conference

Both these calls views can refresh automatically given the interval shown in the “Set Refresh” drop down list. The default is not to refresh however you can choose intervals such as 10 seconds, 20 seconds, 1 minute, 2 minutes, and 5 minutes. You can also refresh the screen yourself using your browser’s “Refresh” function (usually pressing <F5> on your keyboard).

Dropping Call Participants

If during a call, you wish to cancel a conference call for specific participants, you may use the “drop” feature to kick someone off the call. To drop someone from a conference call, first log in to the web interface, then use the following procedure:

1. Click on “Calls” or click on “Conferences”, locate the conference you wish to drop someone from and click on the conference number to bring up the list of callers
2. Click the  button next to the caller you want to drop from the call
3. The system will ask “Are you sure you want to Delete?”
4. Click “OK” to drop the caller.

Mute Call Participants

While a call or a conference is in progress, you can mute the specific participants and listeners using the “Mute” checkbox on Calls window as shown on Figure 14. That means they will be muted, but they will be able to hear the conversation.



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Conference # 133205 secure : OFF | hold : OFF | ASN : OFF | recording : OFF

Keyword: First Name Number of calls: 10 Set refresh:

List records: 1/10 << Previous 1 Next >>

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
 111	(347) 767-4197	<input type="text"/>	919508	05:22:32	153m:36s	conference	host	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
 112	(347) 767-4197	<input type="text"/>	919508	05:22:32	153m:36s	conference	host	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
 114	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
 115	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
 116	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
 117	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
 118	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
 119	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
 120	(347) 767-4197	<input type="text"/>	919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
 Moderator-Console	(347) 767-4197	<input type="text"/>	919508	07:10:53	45m:15s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

Mute Call Participants Checkboxes

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 14: The Location of the Mute Call Participants Checkbox

If you click this checkbox, the specific call participant will be muted.

Placing Call Participants on Hold

While a call or a conference is in progress, you can place the specific participants and listeners on hold using the “Hold” checkbox on Calls window as shown on Figure 15. That means they will hear music and will not be able to hear the conversation.

The screenshot shows the Wyde Voice Conference Appliance Manager interface. At the top, there's a navigation bar with links: Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout. The main header displays 'CONFERENCE APPLIANCE MANAGER'. Below this, a conference details section shows 'Conference # 133205' with a dropdown menu set to 'open'. Status indicators for 'secure', 'hold', 'ASN', and 'recording' are all set to 'OFF'. A 'Dialout' button is visible. A search section includes a 'Keyword' field, a 'First Name' dropdown, and a 'Search' button. To the right, 'Number of calls' is set to '10' and 'Set refresh' is set to 'No Refresh'. The main table lists conference participants with columns: Calling Number, Called Number, User Name, Access Code, Call Begin, Duration, Status, Role, Mute, Hold, and Q&A. A red circle highlights the 'Hold' column checkboxes, with a red arrow pointing to the caption below.

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
111	(347) 767-4197		919508	05:22:32	153m:36s	conference	host	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
112	(347) 767-4197		919508	05:22:32	153m:36s	conference	host	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
114	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
115	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
116	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
117	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
118	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
119	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
120	(347) 767-4197		919508	05:22:33	153m:35s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
Moderator-Console	(347) 767-4197		919508	07:10:53	45m:15s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

Hold Call Participants Checkboxes

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 15: The Location of the Hold Call Participants Checkbox

If you click this checkbox, the specific call participant will be placed on hold.

Conferences


View Conferences in progress


Any time when there are conference calls in progress, you can view them in the web interface. However, when no conferences are in progress, the “Conferences” and “Calls” tabs of the web interface will show no data.

1. Click “Conferences” menu to view all conferences that currently are in process on the bridge (Figure 16). All active conferences will be listed, sorted ascending by conference number. There are several columns of information about each conference. Table 4 details what each column indicates.

Note, you will see all conferences that currently are in process on the bridge only if you login as administrator or a subscriber with operator permissions (see section: Subscriber User Management). If you login as non-operator subscriber you will see only your conferences, i.e. the conferences that belong to you or belong to your subordinate subscribers.

Table 4: Conference View Columns

Column	Description
Conference Number 	The unique number assigned to each conference When clicked, brings up a list of all subscribers in the specified conference
Created	Time conference was started
Duration	How long the conference has been active since the joining of the first caller
Secure	When checked, indicates the conference is secured
Hold	Indicates the entire conference is on hold
Participant Count	Indicates how many participants are currently on this call







24/7 Professional Customer Service
TOLL FREE 866.508.9020

[Subscribers](#) | [Conferences](#) | [Calls](#) | [Reports](#) | [DNIS](#) | [Preferences](#) | [Logout](#) | CONFERENCE APPLIANCE MANAGER

Keyword: Conference Number
 Number of conferences: 2 Set refresh:

List records: 1/2 << Previous | 1 | Next >>

Conference Number ▲	Created	Duration	Secure	Hold	Participant Count
 106149 	20:02:38	463m:59s	<input type="checkbox"/>	<input type="checkbox"/>	2
 179740 	02:41:56	64m:41s	<input type="checkbox"/>	<input type="checkbox"/>	2

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 16: View Conference Information

- Click the conference number of the conference you wish to view. This will bring up the calls window that shows the individual calls that make up this conference (Figure 13, Table 3) as it was previously described in section View Calls in progress.

The conference view can refresh automatically given the interval shown in the “Set Refresh” drop down list. The default is not to refresh however you can choose intervals such as 10 seconds, 20 seconds, 1 minute, 2 minutes, and 5 minutes. You can also refresh

the screen yourself using your browser's "Refresh" function (usually pressing <F5> on your keyboard).

Conference Mute and Q&A Modes

When changes the mode of a conference call, there are different options, or "mute modes" you can choose from to determine how the conference is muted and in what mode is the conference. Figure 17 shows where to select the mode for the conference.

Conference # 106149 **open** secure : OFF | hold : OFF | ASN : OFF | recording : OFF **Dialout**

Keyword: First Name **Search** Number of calls: 2 Set refresh : **No Refresh**

List records: 1/2 << Previous | 1 | Next >>

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
✖ Moderator-Console	(951) 262-1256		931174	20:06:14	496m:14s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
✖ Moderator-Console	(951) 262-1256		931174	20:02:35	499m:53s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

Conference Mode Drop Down List

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.



Figure 17: The Location of the Conference Mode Dropdown

The conference modes are:

- **open** – Anyone can talk and un-mute themselves.
- **relaxed** – All participants will be muted by default, but can un-mute themselves. Hosts are not muted.
- **strict** – None of the participants can un-mute themselves. The only way to un-mute a caller is through the web interface. In this mode, when participant tries to un-mute using *6 – the system tells "conference host has muted the conference, this line can not be unmuted".
- **question** – The conference is in Q&A mode, Q&A Sessions will be described in the next section of this guide. In this mode, if participant presses *6 the system tells "If you'd like to ask a question – press 1".

Q&A Sessions

The WYDE conference software has a feature built in known as Q&A. You can set up a Q&A session from the web administration interface that allows conference participants to, in turn, ask questions and receive answers. The Q&A session can be started either from the Web Administration Interface by selection “question” mode or it can be started by the conference host from DTMF keypad.

When Q&A session is started all participants will be muted and they will be unable to unmute their self, but they will be able to request to speak (to request question). The web interface will show anyone who has requested to speak with an icon  in the Q&A column. You as the host in the web interface can click the icon to allow them to speak, after that this icon will be changed to an icon . Clicking them after they have finished speaking will drop them out of the Q&A queue. You can click the icon in the Q&A column twice to drop the user from the Q&A queue. See Figure 18 to find Q&A session icons.

Furthermore Q&A session can be managed by the conference host using DTMF keypad. To manage Q&A session the host should press *3 (default, but can be overridden) and the following commands are available for him in Q&A session mode:

- 1 – to start Q&A session
- 2 – to move to the next questioner
- 3 – to end Q&A session
- 4 – to mute or unmute the questioner
- 5 – to clear Q&A queue
- * – to return to the conference

Q&A sessions also are described in section Question and Answer Sessions within Conference Calls of this guide.

Conference # 667789 question secure : OFF hold : OFF ASN : OFF recording : OFF Dialout

Keyword: First Name Search Number of calls: 4 Set refresh: No Refresh

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
✖ misha	12	John Smith	1234	05:14:57	00m:37s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>	
✖ 112	(347) 767-4197	Andrew Merrill	711234	05:04:27	11m:07s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
✖ 113	(347) 767-4197		731234	05:04:23	11m:11s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>	
✖ 114	(347) 767-4197		731234	05:04:24	11m:10s	conference	participant	<input type="checkbox"/>	<input type="checkbox"/>	

Conference is in Q&A mode

Conference Q&A Icons

FCC-CA ver. 2.0.6 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 18: The Location of the Q&A Conference Icons

Dropping a Conference

If during a call, you wish to cancel the entire conference call, you may use the “drop” feature to end the conference. To drop the conference call, first log in to the web interface, then use the following procedure:

1. Click on “Conferences”
2. Locate the conference you wish to drop
3. Click the ✖ button next to the conference you want to drop from the call
4. The system will ask “Are you sure you want to Delete?”
5. Click “OK” to drop the caller.

Moreover you can drop the individual conference participants as it was previously described in section: Dropping Call Participants.

Making a Conference Secure

While a conference is in progress, from time to time you may want to make a call secure. That is, make it so that no other participants can join. To do this, log in to the web interface, click on “Conferences” and press “secure : OFF” link – when the conference is secured the link will be changed to “secure : ON”. When the conference is secured you can press “secure : ON” link to release the secure and allow people to join the conference – when the conference is not secured the link will be changed to “secure : OFF”. See Figure 19 to find this link. Note, the secured mode is working for participants and listeners only, hosts can join to the secured conferences.

WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Conference # 106149 open secure : OFF hold : OFF ASN : OFF recording : OFF Dialout

Keyword: First Name Search Number of calls: 2 Set refresh: No Refresh

List records: 1/2 << Previous | 1 | Next >>

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
Moderator-Console	(951) 262-1256		931174	20:06:14	496m:14s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
Moderator-Console	(951) 262-1256		931174	20:02:35	499m:53s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

Secure Conference Link

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 19: The Location of the Secure Conference Link

This secure conference link works like a toggle switch. There could be two possible captions:

secure : OFF – Conference is not secured, i.e. anybody can join to the conference

secure : ON – Conference is secured, i.e. nobody can join to the conference

You can change the conference secure mode simply by clicking on this link.

You may also use the “Secure” checkbox on the “Conferences” main window (shown in Figure 20).



FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 20: The Location of the Secure Conference Checkbox

If you click this checkbox, it will perform the same function as making the conference secure using the “secure : OFF” link in the “Calls” window (Figure 19).

The host also can make the conference secure using DTMF keypad (default: *7) as described in Chapter 3: Call Flows.

Placing a Conference on Hold

While a conference is in progress, you can place all participants and listeners on hold using the hold link. That means they will hear music while hosts have a private discussion. You should press “hold : OFF” link to place the conference on hold – when the conference is on hold the link will be changed to “hold : ON”. When the conference is on hold you can press “hold : ON” link to place the conference on line – when the conference is not on hold the link will be changed to “hold : OFF”. See Figure 21 to find this link.

The screenshot shows the Wyde Voice Web Administration Interface. At the top left is the Wyde Voice logo. At the top right, it says "24/7 Professional Customer Service TOLL FREE 866.508.9020". Below this is a navigation bar with links: Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout |. To the right of the navigation bar is the title "CONFERENCE APPLIANCE MANAGER".

The main content area shows "Conference # 106149" with a dropdown menu set to "open". Below this are status indicators: "secure : OFF", "hold : OFF" (circled in red with a red arrow pointing to it), "ASN : OFF", and "recording : OFF". There is a "Dialout" button. Below these are input fields for "Keyword:" and "First Name" with a "Search" button. To the right, it says "Number of calls: 2" and "Set refresh : No Refresh".

Below the search fields is a table with the following columns: Calling Number, Called Number, User Name, Access Code, Call Begin, Duration, Status, Role, Mute, Hold, and Q&A. The table contains two rows of data, both for "Moderator-Console" with called number "(951) 262-1256". The first row has an access code of "931174", call begin time of "20:06:14", duration of "496m:14s", status of "conference", role of "host", and checkboxes for "Mute" and "Hold". The second row has an access code of "931174", call begin time of "20:02:35", duration of "499m:53s", status of "conference", role of "host", and checkboxes for "Mute" and "Hold".

Below the table is a footer that says "FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved."

Hold Conference Link

Figure 21: The Location of the Hold Conference Link

This hold conference link works like a toggle switch. There could be two possible captions:

- hold : OFF – Conference is on line, i.e. all attendees can hear the conference
- hold : ON – Conference is on hold, i.e. only hosts can talk

You can change the conference hold mode simply by clicking on this link.

You may also use the “Hold” checkbox on the “Conferences” main window (shown in Figure 22).

The screenshot shows the Wyde Voice web interface. At the top, there's a logo for 'WYDE VOICE' and a contact number '24/7 Professional Customer Service TOLL FREE 866.508.9020'. Below this is a navigation bar with links: Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout |. The main title is 'CONFERENCE APPLIANCE MANAGER'. Below the navigation bar, there's a search section with a 'Keyword:' input field, a 'Conference Number' dropdown, a 'Search' button, and a 'Number of conferences: 2' display. To the right, there's a 'Set refresh' dropdown set to 'No Refresh'. Below this is a table with columns: Conference Number, Created, Duration, Secure, Hold, and Participant Count. The 'Hold' column has checkboxes for each conference. A red circle and arrow highlight the 'Hold' checkbox for the first conference (106149). Below the table, the text 'Hold Conference Checkboxes' is written in red.

Conference Number	Created	Duration	Secure	Hold	Participant Count
106149	20:02:38	463m:59s	<input type="checkbox"/>	<input type="checkbox"/>	2
179740	02:41:56	64m:41s	<input type="checkbox"/>	<input type="checkbox"/>	2

Hold Conference Checkboxes

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 22: The Location of the Hold Conference Checkbox

If you click this checkbox, it will perform the same function as putting the conference on hold using the “hold : OFF” link in the “Calls” window (Figure 21).

Moreover you can place on hold the individual conference participants as it was previously described in section: Placing Call Participants on Hold.

Active Speaker Notification (ASN) mode

While a conference is in progress using web interface you can see who is speaking at the moment and how loud the person is speaking. Actually the system shows the loudest four persons and their sound volume. To start active speaker notification you should press “ASN : OFF” – when the mode started the link will be changed to “ASN : ON”. When the active speaker notification is started you can press “ASN : ON” link to stop the notification – when the active speaker notification is not active the link will be changed to “ASN : OFF”. See Figure 23 to find this link.

WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Conference # 134078 secure : OFF | hold : OFF | **ASN : ON** | recording : OFF

Keyword: First Name Number of 2 Set refresh : 10 seconds 8

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
111	12		11233	06:26:28	04m:14s	conference	host		<input type="checkbox"/>	<input type="checkbox"/>
112	12		11233	06:26:29	04m:13s	conference	host		<input type="checkbox"/>	<input type="checkbox"/>

Active Speaker Notification (ASN) Conference Link

Sound volume and who is speaking at the moment

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 23: The Location of the Active Speaker Notification (ASN) Conference Link

This active speaker notification conference link works like a toggle switch. There could be two possible captions:


ASN : OFF – Active speaker notification is not working

ASN : ON – Active speaker notification is working

You can change the conference active speaker notification mode simply by clicking on this link.

Automatic Gain Control

While a conference is in progress and Active Speaker Notification mode is switch on, web admin interface shows you Automatic Gain Controls (AGC) icons for each conference call as shown on Figure 24. If you click on this AGC icon, the Gain Control window appears; this window gives you the opportunity to manage the microphone volume level of the selected call, i.e. gain control option. This value could be from -10 (the quietest/lowest sound level) till 10 (the loudest/highest sound level) or the microphone level (the gain control level) could be automatically adjusted by the WYDE bridge. You can use the slider to set the AGC value of the call or you can check “Auto control” checkbox; after you have moved the slider or checked the checkbox, you should press the “Update” button to apply your changes.


24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Conference # 667788 open secure : OFF | hold : OFF | ASN : ON | recording : OFF | polling : OFF (charts) Dialout

Keyword: First Name Search
Number of calls: 2 Set refresh : No Refresh

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Codec	AGC	Mute	Hold	Q&A
100	12		6602	12:20:42	01m:19s	conference	participant	PCMU		<input type="checkbox"/>	<input type="checkbox"/>	
100	12		6601	12:20:42	01m:19s	conference	host	PCMU		<input type="checkbox"/>	<input type="checkbox"/>	


Gain Control

Auto control: ☐

AGC value: 2 Update

Automatic Gain Controls

Figure 24: The Location of the Automatic Gain Controls (AGC) and the Gain Control Window

When the automatic gain control value is set for the call, near the AGC  icon for that call you will see the icon that represents current gain control value for the call as shown on Figure 25.

AGC	Mute	Hold	Q&A
			AGC value is not set (equal 0)
			AGC value is positive
			AGC control is automatic
			AGC value is negative

Figure 25: The Sample of the Different Gain Controls

Recording a Call

While a conference is in progress, you can record the conference using web interface. To start recording you should press “recording : OFF” – when the recording started the link will be changed to “recording : ON”. When the recording is started you can press “recording : ON” link to stop recording – when the conference is not recording the link will be changed to “recording : OFF”. See Figure 26 to find this link.



CONFERENCE APPLIANCE MANAGER

Conference # 106149 open secure : OFF hold : OFF ASN : OFF recording : OFF Dialout

Keyword: First Name Search Number of calls: 2 Set refresh: No Refresh

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
Moderator-Console	(951) 262-1256		931174	20:06:14	496m:14s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
Moderator-Console	(951) 262-1256		931174	20:02:35	499m:53s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

Recording Conference Link

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 26: The Location of the Recording Conference Link

This recording conference link works like a toggle switch. There could be two possible captions:

recording : OFF – Conference is not being recorded

recording : ON – Conference is being recorded

You can change the conference recording mode simply by clicking on this link.

The host also can start/stop the conference recording using DTMF keypad (default: *9) as described in Chapter 3: Call Flows.

The recorded conferences can be played back either using the Web Administration Interface reporting (as it is described in the section Web Report Management) or by calling to PLAYBACK call flow DNIS numbers and playing the conference on your phone (as it is described in the Chapter 3: Call Flows).

Dialing Another User

Often, there will be a conference call in progress and you will need to call another participant. That is where the dialout feature comes in. If your system supports dialing outside users, log in to the web interface and follow this procedure:

1. Click “Conferences”
2. Click on the Conference you wish to dial out from

- The “Calls” page will open. Click the “*Dialout*” button in the upper right hand corner. You will see a screen similar to Figure 27.



WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Subscriber: Andrew Merrill : 711235 [Host] : (347) 767-4197 - SPECTEL

Phone Number:

Dialout Cancel

FCC-CA ver. 2.0.6 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 27: Dialing Out to Another User

- Select the subscriber you wish to dial from the drop down list.
- Enter the phone number you wish to dial and click the “*Dialout*” button.
- The user will be added to the conference.

Note. There are two possibilities for dialing out to another user:

- If we are able to find the requested conference account (conference user), the screen presented on Figure 27 will be shown to user.
- If we are unable to find the requested conference account (for instance if radius-authorization is used or for some specific call flows) the dialing out screen will have additional field to enter the access code; this field will be pre-populated with the first valid access code of the selected conference.

Polling

While a conference is in progress, you can start polling (voting) for the conference using web interface. To start polling you should press “polling : OFF”, submenu with available polling options (i.e. digits 1, 2, ..., 9, 0) will be opened, and in this submenu you should select available polling options and press “OK” button – after that the link will be changed to “polling : ON” and the polling will be started. When the polling is started you can press “polling : ON” link to stop polling – when the polling session is not started for the conference the link will be changed to “polling : OFF”. See Figure 28 to find this polling link and submenu with available polling options.




Figure 28: The Location of the Polling Conference Link

This polling conference link works like a toggle switch. There could be two possible captions:

polling : OFF – Conference polling session is not in progress

polling : ON – Conference polling session is in progress

You can change the conference polling mode simply by clicking on this link.

The hosts also can start/stop the conference polling using DTMF keypad (default: #5) as described in Chapter 3: Call Flows. When #5 is pressed the following message will be played: “to start the polling session press 1, to return to the conference press *”; when 1 is pressed the following message will be played: “please enter available polling options followed by the #” – after that you should select all possible options (i.e. digits 1, 2, ..., 9, 0) and press # to start polling (the message will inform you what available options are selected and tell you that polling sessions is started). When the polling session is started the conference participants can press #6 to start polling (this command availability is defined by conference extended menu DTMF policy parameter – conference_extended_dtmf, by default parameter value is “hpl”, i.e. polling is available for hosts, participants, listeners); the message “please vote now” will be played next; after that it is possible to select one of the available options or press * to return to the conference (the selected option will be pronounced after your voting). When the polling session is started the hosts can press #5 again to stop the polling session; the following message will be played: “to stop the polling session press 1, to return to the conference press *”; after 1 is pressed the message “the polling session is now over” will be played and the polling session will be ended.


While the conference is in progress (regardless either the polling session is started or it is over) you can see the polling results in the Web Administration Interface using “(charts)” link. For instance if there were two polling sessions (the first with options “1”, “2”, “3” and the second with options “4”, “5”, “6”) the polling charts should look similar to shown on Figure 29.



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout |

CONFERENCE APPLIANCE MANAGER



FCC-CA ver. 2.0.110 ws ver. The requested resource (/version_web.html) is not available©2006-2009 Wyde Voice, All Rights Reserved.

Figure 29: The Conference Polling Session Voting Charts

When the conference is over the results of the conferences polling can be seen using the Web Administration Interface reporting (as it is described in the section Web Report Management).

Scheduling

Any conference could be scheduled to take place at specific date (date range), time, week day (DOW), with specified number of the conference participants. The following call flow attributes (see section: Call Flow Attributes) are responsible for the conference scheduling:

- `conference_scheduled` (Conference scheduled) – denotes if the conference is scheduled or not, this attribute value should be equal “on” for the scheduled conferences, if this attribute value is “off” all scheduling attributes are being ignored;
- `conference_schedule` (Conference schedule) – denotes date (date range), time, day of the week when the conference is scheduled and how many participants can be joined to this scheduled conference, this attribute has the following format:

```
<scheduling 1>[;<scheduling 2>[;<scheduling 3>[;...]]]
```

i.e. this is the list of the conference scheduling records separated with semicolon (;);

each scheduling record has the following format:

```
<part_count>,<days>,<tm_begin>,<duration>,<date_begin>,<date_end>
```

where

- `part_count` – number of participants allowed to the scheduled conference;
- `days` – days of the week when the scheduled conference is allowed: 1 (Sunday), 2 (Monday), ..., 7 (Saturday);
- `tm_begin` – time when the scheduled conference begins in *hhmm* format;
- `duration` – the scheduled conference duration in minutes;
- `date_begin` – the beginning date in *YYMMDD* format when the conference scheduling is active (i.e. the first date when the scheduling is on);
- `date_end` – the ending date in *YYMMDD* format when the conference scheduling is active (i.e. the last date when the scheduling is on)

For example if you need to schedule the conference for 20 participants on Monday, Wednesday, Thursday, from 10:00 a.m. for 90 minutes (i.e. till 11:30 a.m.), for the date range from November 1st, 2009 till March 1st, 2010 the attribute value should be:

20,245,1000,90,091101,100301

If in addition to previous scheduling you need to schedule the conference for 30 participants on November 11th, 2009 (Wednesday) the attribute value should be:
20,245,1000,90,091101,091110;30,4,1000,90,091111,091111;20,245,1000,90,091112,100301

- `conference_schedule_extend_dtmf` (Schedule conference extend DTMF policy) – denotes who (h/p/l, default: h – host) can extend duration of the scheduled conference;
- `conference_schedule_extend_dtmf_binding` (Schedule conference extend DTMF binding) – denotes what keys should be used to extend duration of the scheduled conference, when these keys are pressed the following message will be played: “*please press 1 to extend conference duration for 5 minutes, press 2 – for 10 minutes, press * – to return to the conference*”, the total maximal extension time is defined in the attribute `conference_schedule_extend`;
- `conference_schedule_extend` (Schedule conference extend maximal time in seconds) – denotes to what maximal time in seconds the duration of the scheduled conference can be extended;
- `conference_schedule_remind` (Schedule conference end remind time in seconds) – denotes remind time in seconds before the scheduled conference ends when the reminder (warning) message should be played to the conference host, for instance if this attribute value is 600 before 10 minutes (600 seconds) till the scheduled conference ending time the remind message will be played to the host;
- `conference_schedule_hold` (Wait before scheduled conference begin) – denotes wait time in seconds before the scheduled conference begins when the participants can join; if the participant connected prior to this time his call will be dropped, if he connected after this time but prior the conference begin time music-on-hold will be played to him until the conference starts, for instance if the conference is scheduled to be started at 11:00 and this parameter values is 600 (i.e. 10 minutes) all participants’ calls earlier than 10:50 will be dropped with the message that the conference is scheduled to be started at 11:00, the participants’ calls from 10:50 till 11:00 will be placed on hold (music on hold will be played) until the conference begins.

The sample of call flow attributes that could be used for the conference scheduling is shown on Figure 30.

Conference schedule	<code>conference_schedule</code>	Conference	2,2,1000,90,1001	<input checked="" type="checkbox"/>	2,2,1000,90,100308,100315
Schedule conference extend maximal time in seconds	<code>conference_schedule_extend</code>	DNIS	1800	<input type="checkbox"/>	1800sec = 30min
Schedule conference extend DTMF policy	<code>conference_schedule_extend_dtmf</code>	Conference	h	<input type="checkbox"/>	
Schedule conference extend DTMF binding	<code>conference_schedule_extend_dtmf_binding</code>	DNIS	*9	<input checked="" type="checkbox"/>	300sec = 5min
Wait before scheduled conference begin	<code>conference_schedule_hold</code>	DNIS	300	<input type="checkbox"/>	120sec = 2min
Schedule conference end remind time in seconds	<code>conference_schedule_remind</code>	DNIS	120	<input type="checkbox"/>	
Conference scheduled	<code>conference_scheduled</code>	Conference	on	<input checked="" type="checkbox"/>	

Figure 30: Scheduling Call Flow Attributes Sample

The following conference scheduling logic is being implemented:

- if `conference_scheduled` attribute is “off”, the conference is not scheduled (the processing logic is usual, as for non-scheduled conferences);
- if `conference_schedule` attribute is empty, the conference is not scheduled;
- otherwise, if `conference_scheduled` attribute is “on” and `conference_schedule` attribute describes conference scheduling, the conferences are being considered as scheduled and the following logic will be applied:
 - if there are no any scheduled conferences for the nearest 30 days, the call will be dropped with the message *“This conference has no schedule. Please check with the organizer. Good bye.”*;
 - if for the current day of week all scheduled conferences are already completed, i.e. the current time is more than ending time for the last scheduled conference, the call will be dropped with the message *“Your conference is not running or scheduled. Please check its schedule with the organizer. Good bye.”*;
 - if the time remaining until the scheduled conference beginning time (`<tm_begin>`) is more than an hour the message *“There is no upcoming conference scheduled within an hour. Please check the schedule with the organizer. Good bye.”* will be played and the call will be dropped;
 - if the time remaining until the scheduled conference beginning time (`<tm_begin>`) is less than an hour, but more than period defined in `conference_schedule_hold` attribute value the message *“Your conference will begin in <NNN> minutes. Please call again later. Good bye.”* (where `<NNN>` – minutes till the conference beginning time) will be played and the call will be dropped;
 - if the time remaining until the scheduled conference beginning time (`<tm_begin>`) is less than `conference_schedule_hold` attribute value the message *“Please wait. Your conference will begin shortly. This line is now on hold.”* will be played and the call will be placed on hold (music on hold will be played); at conference beginning time (`<tm_begin>`) the message *“Your conference is started. Please wait while we place you into the conference.”* will be played to inform that the conference is ongoing;
 - if the new call exceeds `<part_count>` amount the call will be dropped with the message *“This conference is already full. Please call again later. Good bye.”*, the host also receives the warning about that;
 - at `conference_schedule_remind` seconds before the conference ending time of the scheduled conference, the host receives announcement *“This conference has <MMM> more minutes to complete. Press <KEY> to request an extension.”* (where `<MMM>` – minutes till the conference ending time, `<KEY>` – keys defined in `conference_schedule_extend_dtmf_binding` call flow attribute value that should be used on DTMF keypad by the host if he wishes to extend the conference duration); the host can extend the conference duration, the maximal extension time is defined in `conference_schedule_extend` attribute value;

- when the scheduled conference time is over the message *“This conference has run out of time. All calls will now end.”* will be played and all this conference calls will be dropped.

Maintaining Conferences Maximal Duration

The WYDE bridge software allows you to define the maximal duration time for your conferences. The following call flow attributes (see section: Call Flow Attributes) are responsible for the conference maximal duration definition:

- `conference_maxduration` (Maximal conference duration) – denotes the maximal duration of the conference; if this attribute value equal `-1` (default) that means that there is no duration limit for the conference, this attribute positive value denotes maximal conference duration in seconds;
- `conference_schedule_extend_dtmf` (Schedule conference extend DTMF policy) – denotes who (h/p/l, default: h – host) can extend maximal duration of the conference;
- `conference_schedule_extend_dtmf_binding` (Schedule conference extend DTMF binding) – denotes what keys should be used to extend maximal duration of the conference, when these keys are pressed the following message will be played: *“please press 1 to extend conference duration for 5 minutes, press 2 – for 10 minutes, press * – to return to the conference”*, the total maximal extension time is defined in the attribute `conference_schedule_extend`;
- `conference_schedule_extend` (Schedule conference extend maximal time in seconds) – denotes to what maximal time in seconds the duration of the conference can be extended, i.e. the maximal conference duration could be `conference_maxduration + conference_schedule_extend`, default this attribute value is `1800` seconds (30 minutes), the conference can be extended multiple times by 5 or 10 minutes by the callers in the roles defined in `conference_schedule_extend_dtmf` attribute using DTMF keys defined in `conference_schedule_extend_dtmf_binding` attribute till maximum time defined in this attribute;
- `conference_schedule_remind` (Schedule conference end remind time in seconds) – denotes remind time in seconds before the conference ends when the reminder (warning) message should be played to the conference host, for instance if this attribute value is `600`, then 10 minutes (600 seconds) before the conference ending time the remind message will be played to the host, default this attribute value is `120` seconds (2 minutes).

Note if the conference is scheduled and it has maximal conference duration defined, the actual maximum conference duration is being defined using the scheduler’s parameters.

The following conference maximal duration logic is being implemented:

- if `conference_maxduration` attribute value is less than `0`, that means that there is no duration limit for the conference, i.e. its duration is unlimited;


- if `conference_maxduration` attribute value is equal to 0, that means that the conference will be stopped immediately after its start, the message *“This conference has exceeded it's time limit. All calls will now end.”* will be played;
- otherwise, if `conference_maxduration` attribute value is positive, this value defines the conference maximal duration in seconds and the following logic will be applied:
 - at `conference_schedule_remind` seconds before the conference ending time of the conference with maximal duration defined and `conference_schedule_extend_dtmf_binding` attribute value not defined, the host receives announcement *“This conference has <MMM> more minutes to complete.”* (where <MMM> – minutes till the conference ending time);
 - at `conference_schedule_remind` seconds before the conference ending time of the conference with maximal duration defined and `conference_schedule_extend_dtmf_binding` attribute value also defined, the host receives announcement *“This conference has <MMM> more minutes to complete. Press <KEY> to request an extension.”* (where <MMM> – minutes till the conference ending time, <KEY> – keys defined in `conference_schedule_extend_dtmf_binding` call flow attribute value that should be used on DTMF keypad by the host if he wishes to extend the conference duration); the host can extend the conference duration, the maximal extension time is defined in `conference_schedule_extend` attribute value;
 - if hosts or callers in the roles defined in `conference_schedule_extend_dtmf` attribute press the keys defined by `conference_schedule_extend_dtmf_binding` attribute they hear the message *“Please press 1 to extend conference duration for 5 minutes, press 2 for 10 minutes, press * to return to the conference.”* and are able to extend the conference duration using these keys;
 - after the conference duration has been extended the message *“Your conference has been extended for <X> minutes.”* will be played (where <X> – either 5 or 10 minutes);
 - if the conference maximal extend time defined by `conference_schedule_extend` attribute is over the message *“We are sorry. Your conference cannot be extended.”* will be played;
 - when the conference maximal duration time is over the message *“This conference has exceeded it's time limit. All calls will now end.”* will be played and all this conference calls will be dropped.

Operator Conferences

Operator conferences and call flows are designed to administrate the conferences and assist the users in case of any problems. In other words operator conferences can be used as quick technical support for users. The operator can monitor the conferences, connect to the different conferences, receive requests from the users, attach the users to the different conferences, dialout, etc. When operator connects to his OPERATOR conference he is being notified when new requests are assigned to his queue or he can initiate the conference surveillance and management.

During the conference any call participants can request a call to an operator. To do that they should press *0 (default, can be overridden); after that the users will be asked to press:

- 1 – to speak to an operator;
- 2 – to post your request and return to your conference.

If the user presses 1 button he will be prompted: “Please wait and you will connect to an operator”, after that he will be placed to the operator queue and will hear music-on-hold while he is waiting operator assistance – when the operator is available he starts private conversation with this user. If the user presses 2 button he will be returned to his conference and he will be able to continue the conversation in his conference while he is waiting operator assistance – when the operator is available he connects to this conference and starts talking to all this conference users. The web interface will show anyone who has requested to call to an operator with an icon  in the Status column as shown on Figure 31.



WYDE VOICE 24/7 Professional Customer Service TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Conference # 362416 open secure : OFF hold : OFF ASN : OFF recording : OFF  Dialout

Keyword: First Name Search Number of calls: 2 Set refresh: No Refresh

List records: 1/2 << Previous 1 | Next >>

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
111	12	John Smith	888002	07:12:26	00m:46s	conference 	host	<input type="checkbox"/>	<input type="checkbox"/>	
112	12	Andrew Merill	888002	06:57:30	15m:42s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

User requested a call to an OPERATOR

Figure 31: Sample Conference Screen when OPERATOR conference is in progress

Any time while the user is waiting the operator response he can press *0 again and he will be asked to press:

- 1 – to cancel the request;
- 2 – to return to the conference.

In addition some call flows can provide that if the user is entering access code three times incorrectly this user is being placed to an operator queue automatically. The operator can assist to such user connect to the requested conference.

Operator conference management can be implemented either using Web Administration Interface or using DTMF keypad on your phone.

Control Operator Conferences Using Touch Tone Commands

Once connected to the operator conference, the host can control the conferences with the touch tone commands given in Table 5.


Table 5: Operator Commands for OPERATOR Call Flow Conferences

Touch Tone Command	Description
*#	Hear the number of users in the service queue, i.e. find out how many users are in the queue
**	Help message (instructions)
*1	Start or stop conference monitor (surveillance call); when the operator presses *1 first time the conference monitoring is being started and the operator is being switched between all started conferences each 30 seconds, when he presses *1 again he has the options – press 1 to connect to the current conference (pause switching between the conferences and hear this current conference only), press 2 to stop conference monitor, or press * to cancel this dialog and continue conference monitor. Note, while the operator is talking to a user (connected to his conference) this command is unacceptable.
*2	Connect to the next user, i.e. receive the call from the user from the operator queue. If the user requested to talk to the operator (using *01) when the operator connects to this user he will hear notification “connecting to the next user”; if the user posted the request (using *02) and returned to his conference when the operator connects to this user conference he will hear notification “connecting to the conference”.
*3	Return current user to his conference or ivr
*4	Connect to another conference; when the operator presses *4 he has the options – press 1 to connect with current user or press 2 to connect without current user; in both cases the operator can press # to connect to the user’s conference or enter conference number followed by the # to connect to another conference; to return back the operator should press *3.
*5	Attach current user to a different conference, i.e. move user to a conference; when the operator presses *5 he hears which number the connected user called to and has the option to press # to connect to the same number or press new DNIS number followed by the #; in both cases he will be asked to enter new access code; after that the current user will be attached to the conference using new DNIS number and access code
*6	Hear current status, for instance “You are not currently connected to any conference”, “You are talking with user from conference NNNNNN”, “You are monitoring the conference NNNNNN”, “You are listening to the conference NNNNNN”, where NNNNNN – the conference number.

Touch Tone Command	Description
*7	Dialing out to another user

All these commands also can be implemented using Web Administration Interface as it is described in the next section of this guide.

Control Operator Conferences Using Web Administration Interface

If the OPERATOR conference is in progress on the “Conferences” view there will be shown operator conference icon  in the “Conference Number” column for the OPERATOR conference (see Figure 32).



WYDE VOICE 24/7 Professional Customer Service TOLL FREE 866.508.9020

Subscribers | **Conferences** | Calls | Back to the Queue | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Keyword: Conference Number: Search


Number of conferences: 2 Set refresh:

List records: 1/2 << Previous | 1 | Next >>

Conference Number	Created	Duration	Secure	Hold	Participant Count
 390008 	06:02:33	02m:24s	<input type="checkbox"/>	<input type="checkbox"/>	2
 667768 	06:04:38	00m:19s	<input type="checkbox"/>	<input type="checkbox"/>	1

OPERATOR conference

Figure 32: View Conference Information when OPERATOR conference is in progress

Once you visited the OPERATOR conference, on other conferences screens (CONF or SPECTEL) the icon  will be shown (see Figure 31); when this icon is pressed the operator will listen the selected conference.

Moreover once you visited the OPERATOR conference the main menu will contain “Back to the Queue” link button; when you click on this button you will go to the last visited OPERATOR conference.

If the user clicks on OPERATOR conference number this conference screen is different from other conferences screens (see Figure 33 and Figure 34). The operator conference screen will have additional controls that are specific for OPERATOR conferences only and allow managing OPERATOR conferences.

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Back to the Queue | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Operator # 390008 secure: OFF | hold: OFF | ASN: OFF | recording: OFF Start listen #: Conference Scan: ☐ Dialout

Keyword: First Name: Search Number of calls: 2 Set refresh:

List records: 1/2 << Previous | 1 | Next >>

Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
	20	Admin Demo	321321	06:02:22	02m:47s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	
	12		11233	06:04:32	00m:37s	conference	host	<input type="checkbox"/>	<input type="checkbox"/>	

Figure 33: Viewing the Callers within an OPERATOR Conference, the user is in an operator queue

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | **Calls** | Back to the Queue | Reports | DNIS | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

Operator # 390008 secure: OFF | hold: OFF | ASN: OFF | recording: OFF Listening #: Conference Scan: ☐ Dialout

Keyword: First Name: Search Number of calls: 2 Set refresh:

List records: 1/2 << Previous | 1 | Next >>



Calling Number	Called Number	User Name	Access Code	Call Begin	Duration	Status	Role	Mute	Hold	Q&A
	20	Admin Demo	321321	06:27:07	10m:33s	conference	host	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	12		11233	06:27:14	10m:26s	conference	host	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	



Figure 34: Viewing the Callers within an OPERATOR Conference, the user is speaking with an operator


OPERATOR conference screen instead of “Conference #” caption will have “Operator #” in the left upper corner of the screen.


Operator can enter conference number he wishes to listen into “Start listen #:” textbox and press enter. If the operator is already listening any conference the caption of this textbox is “Listening #” and this textbox contains the number of the conference operator is listening at the moment; if operator presses icon right after the textbox with conference number, he will disconnect from this conference. This also is managed by “Connect to a conference” call flow attribute and default key for this action is *4.

When the checkbox “Conference Scan:” is checked the operator will start surveillance of the active conferences, i.e. the operator will switch between the conferences and hear each conference 30 seconds. This mode is managed by “Start or stop surveillance call” call flow attribute and default key for this action is *1.

The icon  in the “Status” column means that the user is in the operator queue and waiting the operator response. When the operator is ready to process the users and there are any people in operator queue, they are shown in rose color (Figure 33). To take the next user from the queue the operator should press icon . This action also is managed by “Receive call” call flow attribute and default key for this action is *2. Note that the operator should complete the conversation with the current user before he takes the next user from the queue. If there are users in the operator queue who are waiting the operator response when this page is refreshed there will be ding signal played in the browser to inform you about non-empty operator queue (QuickTime plug-in may be required).

The icon  in the “Status” column indicates that the user is speaking to the operator. This line is shown in light green color (Figure 34). If the operator presses icon  in “User Name” column the user will be disconnected and returned to his conference. The same can be managed by “Return current user to his conference or ivr” call flow attribute and default key for this action is *3.

The icon  in “User Name” column can be used to attach the selected user to a different conference. When you press this icon you will see a screen similar to Figure 35 and you will be asked to enter new DNIS number and access code. This action also can be managed by “Dilaout” call flow attribute and default key for this action is *7.



Attach:	Called number:	3131
	Conference number:	667788
	Access code:	11233

DNIS:

Access Code:

Figure 35: Attach User to a Different Conference

Note if the operator attaches the user to another conference there will be two CDR records with the same session (call) identifier. I.e. on the reports this call will be represented by two rows and they will differ by disconnect reason; see section Web Report Management for details.

As it was previously mentioned OPERATOR conferences can be managed not only via Web Administration Interface, but also using DTMF keypad. The keys that could be used

to manage these conferences are described in the previous section of this guide and in the section OPERATOR of Chapter 3: Call Flows.

Samples and Use-Cases of Operator Conference Procedures

This section of the document will describe few samples about how the operator can assist users in their conference calls.

First of all the operator can monitor (hear) the conference to examine if there are any problems where he can assist.

Also for some call flows the operator will receive automatic requests from users who three times entered incorrect access codes. In this case the operator asks the user information about who he is and about the conference he wish to connect, connects to the requested conference, asks if this conference expecting this user, and if so, returns and attaches the user to this conference.

Moreover the users can request operator assistance in case of any problems, for instance bad audio quality or noises. In this case operator can connect to the user conference and use Web Administration Interface – Active Speaker notification mode (see section Active Speaker Notification (ASN) mode) to examine where is the problem and after that inform the user about the reason of the problems.

In addition the operator can dialout to another user and attach the user to the conference. If call flows do not allow making dialout within the conference the operator assistance is needed.

Web Report Management

One of the most powerful features of the WYDE series of conference bridges is the ability to get information and statistics from the bridges. This information comes mainly in the form of management reports. These reports are run from the web interface primarily.

All of this information can be obtained by first logging in to the web interface, and clicking on the “Reports” menu. You should see a window similar to the one in Figure 36.




Figure 36: Main Reports Window

In this screen, you can see the default report, the Calls Report (which we will discuss later in this chapter). Whenever you view the main reports window, you will see the date range for the report you are looking at. In Figure 36 it shows data for specific date range, all the calls listed fall within that date range. If you wish to change the date range, simply click on either the “From” date or the “To” date and it will bring up a small calendar which you can use to select a new date (Figure 37).



Figure 37: Calendar to Select either the “From” Date or the “To” Date

On the right hand side of the screen, you will see the statistics for this report, including number of calls, and total minutes for all calls. You will also see the navigation bar that will

allow you to navigate between the pages of the report if there is more than one page of call data.

You will also notice a box above each column in the report. These are filter boxes. They are used to filter the report by some data (especially useful if there is too much data to be useful and you need to filter it by some criteria, like time or called user). To filter, type the selection criteria in the box above the column you want to filter by and press enter. The report will be refreshed and only the records matching the criteria will be displayed.

There are seven reports that come standard with each WYDE conferencing appliances. They are:


- **The Calls Report** – Shows all inbound and outbound calls processed by the system during the specified date range. The columns shown on the Calls Report see in Table 6. The Calls Report sample is shown on Figure 38.








Table 6: Calls Report Columns

Column	Description
Call Created	Date and time when the conference was created
Conference Number	The unique number assigned to each conference
Conference Id	The internal unique conference ID
Access code	The conference account access code that was entered
Subscriber Name	The first and last name of the subscriber
Custom Name	The caller custom name if this name was entered in the Web Interface
Called number	The called number, i.e. the number to which called the caller
Calling number	The incoming calling number, i.e. the number from which called the caller
Call duration	Indicates duration of the call
In conference	Indicates how long the call has been active in the conference
Disconnect info - Time	The date and time when the call was disconnected
Disconnect info - Reason	The reason of disconnection, for instance Normal, Dropped by host, Incorrect access code, Moved to other conference. NOANSWER, CONGESTION, etc.
Disconnect info - Initiator	Who initiated the disconnection; possible values: BRIDGE and USER

- **The Conferences Report** – Shows all conferences that have taken place during the specified date range. The columns shown on the Conferences Report see in Table 7. The Conferences Report sample is shown on Figure 39.

Table 7: Conferences Report Columns

Column	Description
Conference Number	The unique number assigned to each conference
Conference Number – 	“Show subscribers” button – when clicked, brings up a list of all subscribers in the specified conference

Column	Description
Conference Number – 	“ <i>See the Gantt chart</i> ” button – when clicked, brings up the Gantt chart for the specified conference (the sample screen is shown on Figure 40). If the participants count exceeds 300 the Gantt chart will not be built.
Conference Number – 	“ <i>See polling results</i> ” button – when clicked, brings up the polling results chart for the specified conference (the sample screen is shown on Figure 29). If there were not the polling sessions for the conference the message “No charts available for this conference.” will be shown.
Recording - 	“ <i>File manager</i> ” button – when clicked, brings up a File Manager for the specified conference (the sample screen is shown on Figure 41). File Manager always shows all recording files that belong to the selected conference number, the files shown in red color belong to recording of the selected conference ID (i.e. the specific conference that occurred in the system), the files shown in black color belong to the same conference number, but to another conference ID; the names of the files are conference ID; the extension “asn” means active speaker file, the extension “ul” means audio file
Recording - 	“ <i>Play recording</i> ” button – when clicked, starts the conference playback
Recording - 	“ <i>Stop recording</i> ” button – when clicked, starts the conference playback
Recording - 	Indicates the conference playback is not available in spite of the conference was recorded (for instance the recording file was deleted or the recording file was not saved because of any internal error)
Recording - 	“ <i>Save recording</i> ” button – when clicked, allows saving the conference playback file (for instance *.wav file)
Recording -	Duration of the conference call
Conference Id	The internal unique conference ID, the conference ID on this report is unique
Created	Date and time when the conference was started
Ended	Date and time when the conference was ended
Duration	Indicates how long the call has been active since the joining of the conference
Number of Calls	Indicates how many calls were made to this conference via the specified conference account

- **The DNIS Report** – Shows the usage of each DNIS and how many calls processed on each DNIS (including outbound calls). The columns shown on the DNIS Report see in Table 8. The DNIS Report sample is shown on Figure 42.

Table 8: DNIS Report Columns

Column	Description
DNIS	The DNIS Association – the combination of the call flow and the actual inbound DNIS number
Number of Calls	Number of calls to DNIS in the selected period
Total Duration	Total duration of all calls to DNIS in the selected period
Average Duration	Average call duration, i.e. Total Duration divided by Number of Calls

- **The Load Chart** – Shows call traffic statistics by time of day during the specified date range. The Load Chart sample is shown on Figure 43.
- **The Show SW Report** – Shows DSP-specific information for the specified date range. The Show SW Report sample is shown on Figure 44.
- **The Show Stat Report** – Shows DNCA statistic information. The Show Stat Report sample is shown on Figure 45.
- **The Show Boards Report** – Shows installed boards and their specific information. The Show Boards Report sample is shown on Figure 46.

Running a report

To run a report, log into the web interface and click on the “Reports” menu. Then, use the following procedure:

1. Enter dates for the date range you wish to view information for by clicking on the dates next to “From:” and “To:” for the start date and end date, respectively.
2. Select the report you wish to view from the drop down list
3. Click the “*Create*” button to run the report
4. The report information will be displayed on the screen. You can change it on the fly by changing any of the parameters you wish to change and clicking the “*Create*” button again.

Report Screenshots

For reference, this section will show figures with samples of the stock reports contained in the standard WYDE installation.




Figure 38: Sample Calls report




Figure 39: Sample Conferences Report



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | **Reports** | DNIS | Preferences | Logout |

CONFERENCE APPLIANCE MANAGER



FCC-CA ver: 2.0.3 ws ver: 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 40: Sample Gantt Chart for the Conference

File Manager for conferences with number 1516527

Filename ▼ ▲	Size ▼ ▲	Last Modification ▼ ▲
57192.ul	23 KB	Sep 4, 2009 6:47:02 AM
57190.asn	340 bytes	Sep 4, 2009 6:40:05 AM
57190.ul	65 KB	Sep 4, 2009 6:40:05 AM
57192.asn	120 bytes	Sep 4, 2009 6:47:02 AM

Figure 41: Sample File Manager for the Conference




Figure 42: Sample DNIS Report



Figure 43: Sample Load Chart




The screenshot shows the WYDE VOICE web administration interface. At the top, there is a logo for WYDE VOICE and a contact number: 24/7 Professional Customer Service TOLL FREE 866.508.9020. Below the logo, there is a navigation bar with links: Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout |. The main header area is labeled 'CONFERENCE APPLIANCE MANAGER'. Below the header, there is a date range selector: From: 08/18/2009 To: 08/18/2009, a dropdown menu for 'Show SW', and a 'Create' button. The main content area displays the output of the 'Show SW' command, which includes a welcome message, the version number (2.0.3), the compilation date (Sep 1 2009), and a list of boards (Boards: 1). The output also shows a serial number (190349) and a list of IDs (id=27e402) with their respective status (0/1150). The footer of the page reads: FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 44: Sample Show SW report



The screenshot shows the WYDE VOICE web administration interface. At the top, there is a logo for WYDE VOICE and a contact number: 24/7 Professional Customer Service TOLL FREE 866.508.9020. Below the logo, there is a navigation bar with links: Subscribers | Conferences | Calls | Reports | DNIS | Preferences | Logout |. The main header area is labeled 'CONFERENCE APPLIANCE MANAGER'. Below the header, there is a date range selector: From: 08/18/2009 To: 08/18/2009, a dropdown menu for 'Show Stat', and a 'Create' button. The main content area displays the output of the 'Show Stat' command, which includes a welcome message, the version number (2.0.3), the compilation date (Sep 1 2009), and statistics for the system. The statistics include: Started: Tue Sep 1 11:50:02 2009, Call: Now=0; Total=765; Peak=15; Controlled=0; Last=Tue Sep 8 05:03:50 2009, and Conf: Now=0; Total=121; Peak=2; Last=Tue Sep 8 05:03:50 2009. The footer of the page reads: FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 45: Sample Show Stat Report



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | **Reports** | DNIS | Preferences | Logout | **CONFERENCE APPLIANCE MANAGER**

From: 08/18/2009 To: 08/18/2009

```
Welcome to WYDE.MP admin console 2.0.3 compiled Sep 1 2009
>Boards: 1
Serial=190349 ID=0x27e402
  DSP[0]: 27e402:0xb7e17ac0 capacity [0/1150], errors 0, online
  DSP[1]: 27e402:0xb7e188b0 capacity [0/1150], errors 0, online
  DSP[2]: 27e402:0xb7e19710 capacity [0/1150], errors 0, online
  DSP[3]: 27e402:0xb7e1a568 capacity [0/1150], errors 0, online
  DSP[4]: 27e402:0xb7e1b3a8 capacity [0/1150], errors 0, online
  DSP[5]: 27e402:0xb7e1c220 capacity [0/1150], errors 0, online
  DSP[6]: 27e402:0xb7e1d058 capacity [0/1150], errors 0, online
  DSP[7]: 27e402:0xb7e1dea8 capacity [0/1150], errors 0, online
>
```

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 46: Sample Show Boards Report

DNIS Management

A DNIS is the unique set of numbers that is outpulsed by a phone carrier that indicates the intended destination for a particular call. It can be any length digits (although usually less than 10 digits). As DNIS number you can also use the mask of the number, in such mask '*' – denotes any sequence of digits and '?' – denotes one single digit; in this case for such DNISes the bridge will process all numbers that comply with the DNIS number mask.

For the purposes of our discussion, a DNIS Association is a combination of a call flow and an actual inbound DNIS number. Chapter 3: Call Flows will be described in the next chapter of this guide.

View Existing DNIS Associations

As with other administration tasks, you can view existing DNIS associations using the web interface.


To view the existing DNIS associations, log in to the web interface, and from the main window of the web administration interface, click on “DNIS”. You will see a screen similar to Figure 47. Notice from this screen you can also see the call flows that are configured on this system.

There are three columns of information for DNISes section of the screen:

- **DNIS** – The actual inbound DNIS number or mask of number
- **Call Flow Name** – The name of the call flow used
- **Description** – A description of this DNIS Association

There are two columns of information for Call Flows section of the screen:

- **Call Flow Name** – The name of the call flow used
- **Directory Path** – The path to call flow scripts and prompts



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | **DNIS** | Preferences | Logout |
CONFERENCE APPLIANCE MANAGER

DNISes
Create

List records: 1/28 << Previous | 1 2 | Next >>

DNIS ▲	Call Flow Name	Description
10	CONF	
111	PLAYBACK	
112	PLAYBACK	test playback account
12	SPECTEL	
15	CONFSE	
19	NCC	
20	OPERATOR	
21	PCCConf	
247	CONF	test
30	CONFSE	
(347) 767-4197	SPECTEL	no pin QA-WCC
(347) 767-4202	STF	added 05-02-2009
(347) 767-4206	CONFSE	added 05-02-2009
(347) 767-4209	CONFSE	added 05-02-2009
(347) 767-4213	CONF	added 05-02-2009
44	PLAYBACK	playback for iPhone client
(443) 701-4583	STF	added 05-02-2009 (8882945724)
(484) 588-4593	CONF	qa TFCC
(484) 588-4609	CONFSE	SE-free talker
(484) 588-4610	CONFSE	SE-free listener

Call Flows

Call Flow Name ▲	Directory Path
CONF	/usr/local/DNCA/callflows/CONF
CONFSE	/usr/local/DNCA/callflows/CONFSE
EMI	/usr/local/DNCA/callflows/EMI
NCC	/usr/local/DNCA/callflows/NCC
OPERATOR	/usr/local/DNCA/callflows/OPERATOR
PCCConf	/usr/local/DNCA/callflows/PCCConf
PLAYBACK	/usr/local/DNCA/callflows/PLAYBACK
PLAYBACKPCCCONF	/usr/local/DNCA/callflows/PLAYBACKPCCCONF
PLAYBACKREFER	/usr/local/DNCA/callflows/PLAYBACKREFER
SPECTEL	/usr/local/DNCA/callflows/SPECTEL
STF	/usr/local/DNCA/callflows/STF

Figure 47: Viewing Existing DNIS Associations and Call Flows

Create a DNIS Association

You can create DNIS association using either the web interface. To create a new DNIS association, simply log in to the web interface and use the following procedure:

1. From the web interface main screen, click “DNIS”. This will bring up the screen previously shown in Figure 47.
2. Click the “Create” button. You will then see a screen similar to the one shown in Figure 48.



WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | **DNIS** | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

*DNIS

*Call Flow Name

Description

Description	Name ▲	Role	Value	Overridden
<div> <div>Create</div> <div>Cancel</div> </div>				

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 48: Creating a New DNIS Association

3. In the field labeled “DNIS” type in the inbound DNIS number you want to be associated with this DNIS Association.
4. From the drop down list labeled “Call Flow Name”, select the call flow to be used with this DNIS Association (CONF in this sample).
5. In the field labeled “Description”, type a description for this DNIS Association.
6. Click the “*Create*” button to finalize creation. The new DNIS will be created and take on the default call flow attributes of the call flow you assigned. It should be noted that you should accept the default attributes of the call flows that area assigned.



Changing any of the default attributes, unless instructed to do so by WYDE technical support, can render your system inoperable.

Modify an Existing DNIS Association’s Attributes

You can change the DNIS number, Call Flow, and Description of any of the DNIS associations using the web interface.

To modify an existing DNIS Association’s attributes using the web interface, log in to the web interface and use the following procedure:

1. Click on any underlined DNIS number. A screen like the one shown in Figure 49 will appear.



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | **DNIS** | Preferences | Logout |

CONFERENCE APPLIANCE MANAGER

*DNIS

*Call Flow Name

Description

Description	Name ▲	Role	Value	Overridden
call				
Delay before answer	call_delay	DNIS	<input type="text" value="2"/>	<input type="checkbox"/>
Maximal calls duration	call_maxduration	DNIS	<input type="text" value="-1"/>	<input type="checkbox"/>
dnis				
Authorize method	dnis_authorizemethod	DNIS	<input type="text" value="local"/>	<input type="checkbox"/>
Language	dnis_language	DNIS	<input type="text" value="default"/>	<input type="checkbox"/>
Maximal number of calls per DNIS	dnis_maxcalls	DNIS	<input type="text" value="-1"/>	<input type="checkbox"/>
Reffered DNIS number	dnis_number	DNIS	<input type="text" value="10"/>	<input type="checkbox"/>
Welcome prompt	dnis_welcomeprompt	DNIS	<input type="text" value="default"/>	<input type="checkbox"/>

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 49: Modify an Existing DNIS Association

- From this screen, you can click in either the “DNIS” or “Description” fields and change the text or select a new Call Flow Name from the “Call Flow Name” drop down list.
- In addition you can override any of default call flow parameters. If you would like to change any of the parameter, the Overridden checkbox should be checked – otherwise the value you entered will not be saved. The list of available parameters depends on selected call workflow name.
The detail description and possible values of each call workflow parameter will be given later in this document in the Chapter 3: Call Flows.
- Once you have made all your changes, click the “Update” button to accept the changes.

Remove a DNIS Association

There will come a time when a DNIS number is no longer in use and should be removed from the system to avoid confusion with active DNIS Associations.

To remove a DNIS association using the web interface, log in to the web interface, click on the DNIS menu, and use the following procedure:


- Click the  button next to the DNIS association you want to delete.
- The interface will ask you “Are you sure you want to delete this DNIS? All registered conferences on this number will be deleted?” as shown on Figure 50.



Figure 50: DNIS Association Deletion Confirmation Dialog

3. Click "OK" to delete the DNIS Association.


System Management

In addition to the daily call administration, you will have to administer the system itself. These system management tasks could be the following:

- Change Initial IP Address
- Change System Name
- Install WYDE Software
- Starting and Stopping the WYDE services
- Managing DSP Cards using Prosody IP Manager

Change System Preferences

To change system preferences you should logon into system and click on “Preferences”. You will see the screen similar to shown on Figure 51.



WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | DNIS | **Preferences** | Logout | CONFERENCE APPLIANCE MANAGER

Preferences

Maximum number of simultaneous calls: 2000

Name of Bridge: QABETA

Rows count on the list forms: 20

Allow Subscribers to modify access codes and create subordinate subscribers: ☒

Update Cancel

FCC-CA ver. 2.0.3 ws ver. 2.0.2 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 51: Changing System Preferences

As you can see you can change the following parameters from this screen:

- **Maximum number of simultaneous calls** – This parameter controls how many calls should be allowed on the system at the same time. This number should be less than the number of supported callers and allows the administrator to limit further the number of callers on the system for performance tuning.
- **Name of Bridge** – This parameter defines the system’s name of the bridge.
- **Rows count on the list forms** – This parameter controls how many rows there are on each page that lists something in the web interface. The default is 20. You can change it to 5, 10, 20, 50, or 100 by selecting the proper number from the drop down list.

- **Allow Subscribers to modify access codes and create subordinate subscribers** – This parameter controls permissions of non-operator (non-admin) subscribers. When this checkbox is unchecked, non-operators cannot create new subscribers and cannot create/modify subscriber conference accounts.

Click the “*Update*” button to make the changes permanent.

Chapter 3: Call Flows

One piece of terminology unique to conference call setup is the idea of a call flow. In other words, the call flow is unique conference call setup, the logic that is used to process the calls; this is the process a call goes through from call setup to, to processing, to call tear down. It includes the logic, DTMF key-presses used, functions, and the recorded prompts. The various system settings and usage parameters are different depending on the call flow used.

The following basic call flows are available in the system:

- CONF
- OPERATOR
- PLAYBACK
- SPECTEL

One of the benefits of the WYDE architecture is the ability to build a complete custom call flow for your organization. So additional custom call flows could be created as customization of the existing call flows. For more information on a custom call flow, please contact your WYDE representative.

Using Web Administration Interface you will be able to change parameters of the call flows, as it will be described later in this chapter. To do so you should login into the system, go to “DNIS” menu, and then click on desired call flow name.

For all call flow the attributes call flow name and directory path will be read-only and you will be unable to change them. But you will be able to change specific call, conference, dnis, and recording attributes. The name of the attributes is started from “call_”, “conference_”, “dnis_”, and “recording_” representing what is the scope of this attribute.

The Call Flow attributes shown on call flow screen are default call attributes. They can be overridden on DNIS configuration level and also can be overridden in the conferences setup for subscribers. In other words the hierarchy of the attributes is the following Call Flows → DNIS Associations → Subscriber Conferences.

The role of an attribute can be either “Conference” or “DNIS”. When the attribute role is “DNIS”, the attribute can be overridden in DNIS Associations only. When the attribute role is “Conference”, the attribute can be overridden either in DNIS Associations or in Subscriber Conferences.

Available attributes are specific for each call flows, but some of them are general and exist in different call flows. The set of available attributes will be described for each call flows.

Any possible user command usually is represented by pair of call flow attributes – the policy attribute and the DTMF binding attribute.

When the attribute defines policy of any option that means the person to whom this option should be available. There could one of the 3 possible policies: “hpl” (the option is available for hosts (h), participants (p), and listeners (l) of the conference), “hp” (the option is available for hosts (h) and participants (p) of the conference), and “h” (the option is

available for conference hosts (h) only). The name of such attribute usually is defined as `<scope>_<command>_dtmf`, for example `call_mute_dtmf` attribute describes the policy of who can mute himself (his call) in the conference and “hp” value means that hosts and participants can mute their calls or `conference_mute_dtmf` attribute describes the policy of who can mute the entire conference and “h” value means that only the hosts can mute the conference.

When the attribute defines binding that means the special functions – the keys (assigned access codes) that should be pressed on telephone keypad to facilitate the call, change any modes of the call, etc. The name of such attribute usually defined as `<scope>_<command>_dtmf_binding`, for example `call_mute_dtmf_binding` attribute describes the keys (default: *6) that should be pressed on your telephone to mute yourself or `conference_mute_dtmf_binding` attribute describes the keys (default: *5) that should be pressed on your telephone to mute the entire conference.

Note that policy attributes usually have “Conference” role, i.e. they can be overridden either in DNIS Associations or in Subscriber Conferences; binding attributes usually have “DNIS” role, i.e. they can be overridden in DNIS Associations only.

Call flow attributes also can define parameters of the calls and conferences, for instance maximum values, switching on or off any calls or conference modes, etc. If the attribute defines maximum value, for instance, Maximal calls duration (`call_maxduration`), Max number of calls per conference (`conference_maxcalls`), Maximal conference duration (`conference_maxduration`), Maximal number of calls per DNIS (`dnis_maxcalls`), etc. the value “-1” means that there is no limit used for this parameter.



Changing any of the call flow attributes, unless instructed to do so by WYDE technical support, can render your system inoperable.

If you would like to edit call flow attributes you should open DNIS section of the portal by clicking the “DNIS” menu and then click on desired call flow name in lower section (Call Flows) of the screen to edit the call flow attributes. The screen should look similar to Figure 52 (the screen sample is given for CONF call flow attributes).



24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | **DNIS** | Preferences | Logout |

CONFERENCE APPLIANCE MANAGER

*Call Flow Name
*Directory Path

call

Description	Name ▲	Role	Value
Announce participant count on enter	call_announceparticipantcount	Conference	<input type="text" value="hp"/>
Delay before answer	call_delay	DNIS	<input type="text" value="2"/>
Exit DTMF policy	call_exit_dtmf	Conference	<input type="text" value="hpl"/>
Exit DTMF binding	call_exit_dtmf_binding	DNIS	<input type="text" value="*3"/>
Instructions DTMF policy	call_instructions_dtmf	Conference	<input type="text" value="hp"/>
Instructions DTMF binding	call_instructions_dtmf_binding	DNIS	<input type="text" value="*4"/>
Maximal calls duration	call_maxduration	DNIS	<input type="text" value="-1"/>
Mute self DTMF policy	call_mute_dtmf	Conference	<input type="text" value="hp"/>
Mute self DTMF binding	call_mute_dtmf_binding	DNIS	<input type="text" value="*6"/>
Call for Operator DTMF policy	call_operator_dtmf	Conference	<input type="text" value=""/>
Call for Operator DTMF binding	call_operator_dtmf_binding	DNIS	<input type="text" value="*0"/>
Tell number of participants during the conference DTMF policy	call_participantsnumber_dtmf	Conference	<input type="text" value="hp"/>
Tell number of participants during the conference DTMF binding	call_participantsnumber_dtmf_binding	DNIS	<input type="text" value="*2"/>

conference

Entry and exit tones DTMF policy	conference_entryexittones_dtmf	Conference	<input type="text" value="h"/>
Entry and exit tones DTMF binding	conference_entryexittones_dtmf_binding	DNIS	<input type="text" value="*8"/>
Entry tones	conference_entrytones	Conference	<input type="text" value="on"/>
Exit tones	conference_exittones	Conference	<input type="text" value="on"/>
Lock conference DTMF policy	conference_lock_dtmf	Conference	<input type="text" value="h"/>

Figure 52: Modifying CONF Call Flow Attributes

Call Flow Attributes

As it was previously told available attributes are specific for each call flows, but some of them are general and exist in different call flows. Possible call flow attributes are listed in Table 9.

Table 9: Call Flow Attributes
Attribute Description
(Attribute Name)

	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
call					
Announce participant count on enter (call_announceparticipantcount)	C	—	—	C	Denotes to which users (h/p/l ²) will played the current number of participants when he connected to the conference
Associate audio key DTMF policy (call_associate_dtmf)	C	—	—	—	Denotes who (h/p/l) can associate the audio key for the conference
Associate audio key DTMF binding (call_associate_dtmf_binding)	D	—	—	—	Denotes what keys should be used to associate the audio key for the conference (default: #9); the audio key is used to group the calls (for instance it is used to group different types of calls); the user is pressing #9audio key#, this info is stored in the database; the calls with the same audio key are being grouped together into the bundle, and to such groups can be performed grouped commands using Real Time interface
Connect to a conference DTMF policy (call_connect2conf_dtmf)	—	C	—	—	Denotes who (usually – host) can connect to another conference using OPERATOR call flow
Connect to a conference DTMF binding (call_connect2conf_dtmf_binding)	—	C	—	—	Denotes what keys should be used to connect to another conference (default: *4); when these keys are pressed the system starts the dialog to select to which conference it is necessary to connect and who (host operator and/or currently connected user) should be connected to this conference
Delay before answer (call_delay)	D	D	D	D	The delay in seconds between invitation from the user and the playing of the welcome prompt message (default: 2 seconds)
Return current user to his conference or ivr DTMF policy (call_dropuser_dtmf)	—	C	—	—	Denotes who (usually – host) can drop the user from OPERATOR conference and return him to his original conference
Return current user to his conference or ivr DTMF binding (call_dropuser_dtmf_binding)	—	C	—	—	Denotes what keys should be used to drop the user from OPERATOR conference and return him to his original conference (default: *3)
Exit DTMF policy (call_exit_dtmf)	C	—	—	C	Denotes who (h/p/l) can exit from the conference
Exit DTMF binding (call_exit_dtmf_binding)	D	—	—	D	Denotes what keys should be used to exit from the conference (default: *3)
Gain control decreasing policy (call_gaindec_dtmf)	C	—	—	C	Denotes who (h/p/l) can decrease the microphone volume level of the call (gain control option)
Gain control decreasing binding (call_gaindec_dtmf_binding)	D	—	—	D	Denotes what keys should be used to decrease the microphone volume level of the call
Gain control increasing policy (call_gaininc_dtmf)	C	—	—	C	Denotes who (h/p/l) can increase the microphone volume level of the call (gain control option)
Gain control increasing binding (call_gaininc_dtmf_binding)	D	—	—	D	Denotes what keys should be used to increase the microphone volume level of the call
Find out how many users are in the queue DTMF policy (call_find_dtmf)	—	C	—	—	Denotes who (usually – host) can request telling how many users are in the OPERATOR queue line
Find out how many users are in the queue DTMF binding (call_find_dtmf_binding)	—	C	—	—	Denotes what keys should be used to play how many users in the OPERATOR queue line (default: *#)
Instructions DTMF policy call_instructions_dtmf	C	C	—	C	Denotes who (h/p/l) can play the instructions (i.e. help message) about available commands

¹ “C” – conference, “D” – DNIS, “—” – not used in the call flow² “h” – hosts, “p” – participants, “l” – listeners

Attribute Description (Attribute Name)	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
Instructions DTMF binding (call_instructions_dtmf_binding)	D	C	–	D	Denotes what keys should be used to play instructions about the keys and their purposes (default: **)
Enter job code when joins the conference (call_jobcodeonenter)	C	–	–	C	Denotes to whom (usually – host) the system should ask to enter numeric job code; the job code is being asked after entering access code; this job code is being saved in the database and it could be used for different purposes, such as reporting, etc.
Maximal calls duration (call_maxduration)	D	–	D	D	Denotes maximum call duration, default value: -1 – that means unlimited call duration
Move user to a conference DTMF policy (call_move2conf_dtmf)	–	C	–	–	Denotes who (usually – host) can move the user from the OPERATOR conference to another conference
Move user to a conference DTMF binding (call_move2conf_dtmf_binding)	–	C	–	–	Denotes what keys should be used to move the user from the OPERATOR conference to another conference (default: *5)
Mute self DTMF policy (call_mute_dtmf)	C	–	–	C	Denotes who (h/p/l) can mute himself using DTMF
Mute self DTMF binding (call_mute_dtmf_binding)	D	–	–	D	Denotes what keys should be used by user to mute himself; note, when the user mutes himself using DTMF keyboard the systems knows that the user makes mute and it is shown in the Web Administration Interface Conferences/Calls screens, when the user mute himself using “mute” key on his phone, the system does not know that and it is not shown on the Web
Call operator after number of unsuccessful attempts to enter access code (call_operator_after)	D	D	D	D	Denotes number of unsuccessful attempts to enter access code after which the call will be forwarded to the operator conference
Call for Operator DTMF policy (call_operator_dtmf)	C	–	–	C	Denotes who (h/p/l) can call to operator (go to OPERATOR queue)
Call for Operator DTMF binding (call_operator_dtmf_binding)	D	–	–	D	Denotes what keys should be used to call to OPERATOR queue (default: *0)
Tell number of participants during the conference DTMF policy (call_participantsnumber_dtmf)	C	–	–	C	Denotes who (h/p/l) can request telling the current number of participants for the conference
Tell number of participants during the conference DTMF binding (call_participantsnumber_dtmf_binding)	D	–	–	D	Denotes what keys should be used to tell the current number of participants for the conference (default: *2)
Hear current status DTMF policy (call_status_dtmf)	–	C	–	–	Denotes who (usually – host) can hear the OPERATOR conference current status; for instance when the operator is connected to some conference, the status tells to what conference the operator is connected
Hear current status DTMF binding (call_status_dtmf_binding)	–	C	–	–	Denotes what keys should be used to hear current operator conference status (default: *6)
Start or stop surveillance DTMF policy (call_surveillance_dtmf)	–	C	–	–	Denotes who (usually – host) can start and stop the conference surveillance, i.e. the cycle of listening of the active conferences
Start or stop surveillance call DTMF binding (call_surveillance_dtmf_binding)	–	C	–	–	Denotes what keys should be used to start and stop the conference surveillance mode (default: *1)
Receive call DTMF policy. (call_talk_dtmf)	–	C	–	–	Denotes who (usually – host) can take the user from OPERATOR queue to the operator conference
Receive call DTMF binding. (call_talk_dtmf_binding)	–	C	–	–	Denotes what keys should be used to take the user from the OPERATOR queue to the operator conference (default: *2)

Attribute Description (Attribute Name)	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
<u>conference</u>					
Application specific data (conference_appspecific)	C	—	—	C	Denotes data that could be used by external custom application
Callers database (conference_callerdb)	—	C	—	C	Denotes should be or should not be saved in the database the custom name from the web; it is dropdown with two possible values on and off (default: off); if the parameter switched on the custom name will be saved and the next time when the same user (the user with the same calling number and access code) will be connected, this custom name will be shown
Dialout DTMF policy (conference_dialout_dtmf)	—	C	—	C	Denotes who (h/p/l) can make a call to another user to connect him to the conference
Dialout DTMF binding (conference_dialout_dtmf_binding)	—	D	—	D	Denotes what keys should be used to dialout to another user to connect him to the conference
Mask dids for operator (conference_dids_mask)	—	C	—	—	Denotes the mask of DNIS numbers that may be serviced (default: * – all DNIS numbers); note: DNIS and DIDS are synonyms here
Distributed conferencing (conference_distributed)	C	—	—	C	Denotes should or should not the conferences between different bridges (i.e. distributed conferences) be allowed; it is dropdown with two possible values on and off (default: off)
Entry and exit tones DTMF policy (conference_entryexittones_dtmf)	C	—	—	C	Denotes who (usually – host) can manage entry and exit tones of the conference
Entry and exit tones DTMF binding (conference_entryexittones_dtmf_binding)	D	—	—	D	Denotes what keys should be used to manage the entry and exit tones of the conference (default: *8)
Entry tones (conference_entrytones)	C	—	—	C	Denotes should or should not be played entry tones (beep sound) when the user enters to the conference; it is dropdown with two possible values on and off (default: on)
Exit tones (conference_exittones)	C	—	—	C	Denotes should or should not be played exit tones (beep sound) when the user exits from the conference; it is dropdown with two possible values on and off (default: on)
Conference extended menu DTMF policy (conference_extended_dtmf)	—	—	—	C	Denotes who (host, participant, listener) can use extended menu for the conference.
Conference extended menu DTMF binding (conference_extended_dtmf_binding)	—	—	—	D	Denotes what keys should be used to enter into extended menu (default: #); extended menu entries are #1, #2, #3, #4 – enter to the sub-conference, #5 – start/stop polling (available for hosts only regardless of the policy attribute value), #6 – vote (when the polling is in progress), #9 – enter audio key (the audio key is used to group the calls (for instance it is used to group different types of calls); the user is pressing #9audio key#, this info is stored in the database; the calls with the same audio key are the group, and to such groups can be performed grouped commands using Real Time interface) .
Extra services URIs (conference_extra)	—	—	—	C	Denotes URI to external VoIP application that could be used as the conference plug-in

Attribute Description (Attribute Name)	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
Hold policy for participant (conference_hold_participant)	–	–	–	C	Denotes should participants or should not hear each other (be on hold) when there are no hosts in the conference (only participants connected to the conference); when the attribute is set to true all participants will be on hold (will not hear each other) when there are no hosts in the conference, when the attribute is set to false all participants will hear each other even if there are no hosts in the conference; it is dropdown with two possible values true and false (default: false)
Enter job code DTMF policy (conference_jobcode_dtmf)	C	C	–	C	Denotes who (usually – host) can change the job code that was entered when the call was started; see call_jobcodeonenter
Enter job code DTMF binding (conference_jobcode_dtmf_binding)	D	D	–	D	Denotes what keys should be used to change job code
Language (conference_language)	C	C	C	C	Denotes the dialog language (default)
Lock conference DTMF policy (conference_lock_dtmf)	C	–	–	C	Denotes who (h/p/l) can place the entire conference in the secure mode (see section: Making a Conference Secure)
Lock conference DTMF binding conference_lock_dtmf_binding	D	–	–	D	Denotes what keys should be used to place the conference in the secure mode (default: *7)
Max number of calls per conference (conference_maxcalls)	C	–	–	C	Denotes maximum number of calls per conference, default value: -1 – that means unlimited number of calls
Maximal conference duration conference_maxduration	D	–	–	D	Denotes maximum conference duration, default value: -1 – that means unlimited conference duration
Music on hold (conference_moh)	C	C	–	C	Denotes prompt that is played when the conference is on hold (default – means default on hold message); the following attribute formats are valid: <ul style="list-style-type: none"> • <code><filename></code> – play the file as music on hold; • <code><filename>:AC:<period></code> – play the file as music on hold and in the given <i>period</i> pronounce the access code that was entered; • <code><filename>:ADV:<period>:<keys></code> – denotes that advertising messages should be played in the given <i>period</i>, <i>dnis_aduri</i> call flow attribute also should be set, <i><keys></i> – is the list of advertising keys separated with ampersand (&) that should be used to play the messages (i.e. <code>key1[&key2[&key3]]</code>) See “ <i>Command Line Administration Interface – User Guide</i> ”, section “ <i>Audio Prompts Management</i> ” for information how to use own audio files in music on hold prompts
Mute mode DTMF policy (conference_mute_dtmf)	C	–	–	C	Denotes who (h/p/l) can mute the conference (see section: Conference Mute and Q&A Modes); note that depending on the conference mode the participants can or can not un-mute their self
Mute mode DTMF binding conference_mute_dtmf_binding	D	–	–	D	Denotes what keys should be used to mute the conference (default: *5)
Mute policy for listener (conference_mute_listener)	–	–	–	C	Denotes can or can not the listeners un-mute their self; it is dropdown with three possible values: open (un-muted), relaxed, (muted, but can un-mute their self, strict (can not be un-muted) (default: strict)

Attribute Description (Attribute Name)	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
Get participants count and detailed participants info DTMF policy (conference_participantsinfo_dtmf)	C	—	—	C	Denotes who (h/p/l) can play participants count and detailed participants info into the conference
Get participants count and detailed participants info DTMF binding (conference_participantsinfo_dtmf_binding)	D	—	—	D	Denotes what keys should be used to get participants count and detailed participants info
Q&A session DTMF policy (conference_qa_dtmf)	C	—	—	C	Denotes who (h/p/l) can place the entire conference in the Q&A (question) session mode (see section: Conference Mute and Q&A Modes)
Q&A session DTMF binding conference_qa_dtmf_binding	D	—	—	D	Denotes what keys should be used to place the conference in Q&A mode (default: *3)
Realtime protocol (conference_realtime)	C	C	—	C	Denotes should or should not the realtime protocol be switched for the conference; it is dropdown with two possible values on and off (default: on)
Conference roll call default (conference_rollcall)	C	—	—	C	Denotes should or should not the system ask the user to introduce himself when he joined to the conference; it is dropdown with two possible values on and off (default: off)
Entry name (conference_rollcall_onenter)	C	—	—	C	Denotes should or should not the system pronounce the name of the user who has entered to the conference; it is dropdown with two possible values on and off (default: off)
Exit name (conference_rollcall_onexit)	C	—	—	C	Denotes should or should not the system pronounce the name of the user who has exited from the conference; it is dropdown with two possible values on and off (default: off)
Conference schedule (conference_schedule)	—	—	—	C	Contains the information describing when the conference is scheduled (date, time, DOW) and how many participants allowed for this conference (see section: Scheduling for details)
Schedule conference extend maximal time in seconds (conference_schedule_extend)	—	—	—	D	Denotes to what maximal time in seconds the duration of the scheduled conference can be extended
Schedule conference extend DTMF policy (conference_schedule_extend_dtmf)	—	—	—	C	Denotes who (h/p/l) can extend duration of the scheduled conference
Schedule conference extend DTMF binding (conference_schedule_extend_dtmf_binding)	—	—	—	D	Denotes what keys should be used to extend duration of the scheduled conference
Wait before scheduled conference begin (conference_schedule_hold)	—	—	—	D	Denotes wait time in seconds before the scheduled conference begins the participants can join; if the participant connects prior to this time his call will be dropped, if he connects after this time but prior the conference begin time music-on-hold will be played to him until the conference starts
Schedule conference end remind time in seconds (conference_schedule_remind)	—	—	—	D	Denotes remind time in seconds before the scheduled conference ends when the reminder (warning) message should be played to the host
Conference scheduled (conference_scheduled)	—	—	—	D	Denotes if the conference is scheduled or not; it is dropdown with two possible values: on and off (default: off)
How conference begins (conference_start_how)	—	—	—	C	Denotes when the conference begins; it is dropdown with two possible values: first (the conference begins when the first participant connected) and moderator (the conference begins when the first host/moderator connected); default: first
Wait to start without moderator (conference_start_wait)	—	—	—	C	Denotes the time in seconds (for instance 300 seconds) how long the conference should wait until moderator connects to the conference – after this number of seconds the entire conference will be ended and all participants will be dropped

Attribute Description (Attribute Name)	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
How conference ends (conference_stop_how)	C	—	—	C	Denotes when the conference ends; it is dropdown with two possible values: last (the conference ends when the last participant disconnected) and moderator (the conference ends when the host/moderator disconnected); default: last
Wait before disconnect when moderator left the conference (conference_stop_wait)	C	—	—	C	Denotes the time in seconds (for instance 300 seconds) how long the conference should be active after the moderator left the conference – after this number of seconds the entire conference will be ended and all participants will be dropped
<u>dnis</u>					
Ad key (dnis_adkey)	D	—	—	—	Denotes key (password) to advertising message that will be played when the user connects to the conference; the message is being played only if the key is not empty
Ad URI (dnis_aduri)	D	—	—	—	Denotes URI (URL) to advertising message that will be played when the user connects to the conference
Authorize method (dnis_authorizemethod)	D	D	D	D	Denotes conference authorization method; it is dropdown with five possible values: free (no access code verification performed, i.e. any access code is allowed), local (perform access code verification, i.e. the access code must be valid), vsrradius, wyderadius (RADIUS verification performed), ldap (LDAP verification performed)
Billing rule (dnis_billingrule)	D	D	D	D	Denotes conference billing rule that is used to store and/or transmit CDR data that could be used for billing (default billing rule: <i>default</i>)
Conference numbers domain (dnis_domain)	—	D	—	—	It is used in call flows with free authorization, this allows to the calls from different DNIS numbers go to different conferences based on access codes entered by users and this DNIS domain value
Languages list for accesscode prompt (dnis_language_list)	D	—	—	—	Denotes semicolon-separated list of languages that are being used for access code prompt; if it is empty – only conference language will be used (for instance the sequence EN:DE:IT defines three languages that will be sequentially used in the prompt to enter access code)
Maximal number of calls per DNIS (dnis_maxcalls)	D	D	D	D	Denotes maximum number of calls per DNIS, default value: -1 – that means unlimited number of calls
Reffered DNIS number (dnis_number)	—	—	D	—	Denotes the DNIS number to playback the conference, for instance 10 means that the conference with DNIS number 10 can be played back using this PLAYBACK call flow
Playback number (dnis_playbacknumber)	—	—	—	D	Denotes the playback number that can be used to playback the recorded conferences
Validate subscriber pin (dnis_validatesubscriberpin)	—	—	—	D	Denotes should or should not the system ask and validate subscriber PIN; it is dropdown with two possible values: on and off (default: off)

Attribute Description (Attribute Name)	Call Flows Roles ¹				Notes
	CONF	OPERATOR	PLAYBACK	SPECTEL	
Welcome prompt (dnis_welcomeprompt)	D	D	D	D	Denotes the message that is played before entering access code (or <i>default</i>); the welcome prompt files should be placed into the folder <i>/usr/local/DNCA/var/welcome-prompts/</i> ; for <i>CONF</i> call flow if the custom welcome prompt and <i>dnis_language_list</i> attributes values are defined the system will use welcome prompt files for each of the defined languages, the files names are being formed as <i><welcome prompt file name>_<language></i> (if the file for specific language not found the file with the name <i><welcome prompt file name></i> will be used instead of that)
<u>recording</u>					
Recording server address (recording_addr)	D	D	—	D	Denotes recording server address if remote or remote_trusted recording method is used
Recording DTMF policy (recording_dtmf)	C	—	—	C	Denotes who (h/p/l) can start the recording (see Recording a Call)
Recording DTMF binding (recording_dtmf_binding)	D	—	—	D	Denotes what keys should be used to start and stop the recording
Recording method (recording_method)	D	D	—	D	Denotes recording method; it is dropdown with four possible values: local (local server, subscriber PIN should be entered), local_trusted (local server, subscriber PIN should not be entered), remote (remote server, subscriber PIN should be entered), remote trusted (remote server, subscriber PIN should not be entered); (see recording_addr attribute)
How recording ends (recording_stop_how)	—	—	—	C	Denotes when the recording should be ended; it is dropdown with two possible values: last (the recording ends when the last participant disconnected) and moderator (the recording ends when the host/moderator disconnected); default: last
Wait before stop recording when moderator left the conference (recording_stop_wait)	—	—	—	C	Denotes the time in seconds (for instance 0 seconds) how long the recording should continue before stopping after the moderator left the conference – after this number of seconds the recording will be stopped

CONF

The CONF call is a normal conference call setup with no security. All participants use the conference number as the access code and the only differentiator between host and participant is the termination of the login – hosts use *, participants use #.

Open DNIS section of the portal by clicking the “DNIS” menu. Then click “CONF” in lower section (Call Flows) of the screen to edit CONF call flow attributes. The screen should look similar to Figure 52. Available CONF call flow attributes are listed in Table 10.

Table 10: CONF Call Flow Attributes

Attribute Description	Attribute Name	Role	Default Value	Notes
<u>call</u>				
Announce participant count on enter	call_announceparticipantcount	Conference	hp	Available for hosts (h) and participants (p)
Associate audio key DTMF policy	call_associate_dtmf	Conference		
Associate audio key DTMF binding	call_associate_dtmf_binding	DNIS	#9	
Delay before answer	call_delay	DNIS	2	
Exit DTMF policy	call_exit_dtmf	Conference	hpl	Available for hosts (h), participants (p), and listeners (l)
Exit DTMF binding	call_exit_dtmf_binding	DNIS	*3	
Gain control decreasing policy	call_gaindec_dtmf	Conference		
Gain control decreasing binding	call_gaindec_dtmf_binding	DNIS		
Gain control increasing policy	call_gaininc_dtmf	Conference		
Gain control increasing binding	call_gaininc_dtmf_binding	DNIS		
Instructions DTMF policy	call_instructions_dtmf	Conference	hp	Available for hosts (h) and participants (p)
Instructions DTMF binding	call_instructions_dtmf_binding	DNIS	**	
Enter job code when joins the conference	call_jobcodeonenter	Conference		
Maximal calls duration	call_maxduration	DNIS	-1	
Mute self DTMF policy	call_mute_dtmf	Conference	hp	Available for hosts (h) and participants (p)
Mute self DTMF binding	call_mute_dtmf_binding	DNIS	*6	
Call operator after number of unsuccessful attempts to enter access code	call_operator_after	DNIS	3	
Call for Operator DTMF policy	call_operator_dtmf	Conference	hp	
Call for Operator DTMF binding	call_operator_dtmf_binding	DNIS	*0	
Tell number of participants during the conference DTMF policy	call_participantsnumber_dtmf	Conference	hp	Available for hosts (h) and participants (p)
Tell number of participants during the conference DTMF binding	call_participantsnumber_dtmf_binding	DNIS	*2	
<u>conference</u>				
Application specific data	conference_appspecific	Conference		
Distributed conferencing	conference_distributed	Conference	off	Selected in dropdown list, other value: on
Entry and exit tones DTMF policy	conference_entryexittones_dtmf	Conference	h	Available for hosts (h) only
Entry and exit tones DTMF binding	conference_entryexittones_dtmf_binding	DNIS	*8	
Entry tones	conference_entrytones	Conference	on	Selected in dropdown list, other value: off
Exit tones	conference_exittones	Conference	on	Selected in dropdown list, other value: off
Enter job code DTMF policy	conference_jobcode_dtmf	Conference	h	Available for hosts (h) only
Enter job code DTMF binding	conference_jobcode_dtmf_binding	DNIS	*4	
Language	conference_language	Conference	default	
Lock conference DTMF policy	conference_lock_dtmf	Conference	h	Available for hosts (h) only
Lock conference DTMF binding	conference_lock_dtmf_binding	DNIS	*7	
Max number of calls per conference	conference_maxcalls	Conference	-1	

Attribute Description	Attribute Name	Role	Default Value	Notes
Maximal conference duration	conference_maxduration	DNIS	-1	
Music on hold	conference_moh	Conference	default	
Mute mode DTMF policy	conference_mute_dtmf	Conference	h	Available for hosts (h) only
Mute mode DTMF binding	conference_mute_dtmf_binding	DNIS	*5	
Get participants count and detailed participants info DTMF policy	conference_participantsinfo_dtmf	Conference		
Get participants count and detailed participants info DTMF binding	conference_participantsinfo_dtmf_binding	DNIS		
Q&A session DTMF policy	conference_qa_dtmf	Conference	h	Available for hosts (h) only
Q&A session DTMF binding	conference_qa_dtmf_binding	DNIS	*1	
Realtime protocol	conference_realtime	Conference	off	Selected in dropdown list, other value: on
Conference roll call default	conference_rollcall	Conference	off	Selected in dropdown list, other value: on
Entry name	conference_rollcall_onenter	Conference	off	Selected in dropdown list, other value: on
Exit name	conference_rollcall_onexit	Conference	off	Selected in dropdown list, other value: on
How conference ends	conference_stop_how	Conference	last	Selected in dropdown list, other value: moderator
Wait before disconnect when moderator left the conference	conference_stop_wait	Conference	300	
<u>dnis</u>				
Ad key	dnis_adkey	DNIS		
Ad URI	dnis_aduri	DNIS		
Authorize method	dnis_authorizemethod	DNIS	free	Selected in dropdown list, other values: local, vsrradius, wyderadius, ldap
Billing rule	dnis_billingrule	DNIS	default	
Languages list for accesscode prompt	dnis_language_list	DNIS		
Maximal number of calls per DNIS	dnis_maxcalls	DNIS	-1	
Welcome prompt	dnis_welcomeprompt	DNIS	default	
<u>recording</u>				
Recording server address	recording_addr	DNIS	0	
Recording DTMF policy	recording_dtmf	Conference	h	Available for hosts (h) only
Recording DTMF binding	recording_dtmf_binding	DNIS	*9	
Recording method	recording_method	DNIS	local	Selected in dropdown list, other values: local_trusted, remote, remote_trusted

Sample of Conference Call Procedures Using the CONF Call Flow

This section describes the basic procedures used within a conference call that uses the CONF call flow. These procedures should be somewhat familiar to you if you have ever moderated or participated in a conference call.

Entering conference call as a Host

The person responsible for managing the conference call while in progress is known as the Host. This person has special functions they can use to facilitate the call. The following is the procedure for entering a conference call:

1. Dial the host number, wait for the welcome prompt.
2. When prompted, enter the assigned access code, followed by the *key.
3. Once connected to the live conference, the host can control the call with the commands given in Table 11.

Table 11: Host Commands for CONF Call Flow Conferences

Touch Tone Command	Description
*2	Count – plays the number of parties in the call
*3	Exit – exit the conference call
*4	Instructions – conference instructions
*5	Listen only modes – host controlled muting
*6	Mute/Unmute – caller controlled muting
*7	Secured/Unsecured – stops callers from entering
*8	Entry and Exit Tones Control

Entering a conference call as a Participants

If you are entering a conference call as a participant on a WYDE bridge that is set up with the CONF call flow, use the following procedure:

1. Dial the host number, wait for the welcome prompt.
2. When prompted, enter the assigned access code, followed by the # key.
3. Once connected to the live conference, every caller will be able to talk. Every caller will also have access to the touch tone commands listed in Table 12.

Table 12: Participant Commands for CONF Call Flow Conferences

Touch Tone Command	Description
*3	Conference Exit
*4	Conference Instructions
*5	Mute line on/off

Question and Answer Sessions within Conference Calls

It is possible to use the conference call flows CONF or SPECTEL for modified Q&A sessions.

Once inside a conference call, to use the Q&A feature, the host can begin a Q&A session by using the following procedure (this procedure assumes the CONF call flow – other flows may have different key bindings, but the basic procedure is the same):

1. From within an active conference, the host puts conference on mute in strict mode using *5.
2. Host then announces to the conference that they can ask questions by pressing *6.
3. Each participant can press *6 and confirm that he wants to ask a question. The participants will be placed in a queue in the order that they pressed *6.

4. Once the conference has been muted, the host can press *0 1 to start Q&A session. Each participant, in turn, will then be unmuted to ask their question.
5. To move to the next question – host should press *0 1 again.
6. There is an option to mute current questioner without kicking them from the queue – *0 2.
7. To stop the Q&A session, then host should press *0 3.

You can also control the Q&A session from the web. To do this, use the procedure described in the chapter Conferences and Calls Management of this guide.

OPERATOR

The OPERATOR call is used for administrative purposes; it is not used for actual conferences. The operator can receive requests from the users who wish to talk with him; if the operator accepts the request the new conference with two participants is being started. The operator also can manage this user, for instance move him to another conference or listen to the conference of this user (the conference where the user came from). In addition, for instance, the operator can connect to any conference without being noticed. The operator functions can be implemented either from the web interface or using touch tone commands.

Open DNIS section of the portal by clicking the “DNIS” menu. Then click “OPERATOR” in lower section (Call Flows) of the screen to edit OPERATOR call flow attributes. The screen should look similar to Figure 52. Available OPERATOR call flow attributes are listed in Table 13.

Table 13: OPERATOR Call Flow Attributes

Attribute Description	Attribute Name	Role	Default Value	Notes
<u>call</u>				
Connect to a conference DTMF policy	call_connect2conf_dtmf	Conference	h	Available for hosts (h) only
Connect to a conference DTMF binding	call_connect2conf_dtmf_binding	Conference	*4	
Delay before answer	call_delay	DNIS	3	
Return current user to his conference or ivr DTMF policy	call_dropuser_dtmf	Conference	h	Available for hosts (h) only
Return current user to his conference or ivr DTMF binding	call_dropuser_dtmf_binding	Conference	*3	
Find out how many users are in the queue DTMF policy	call_find_dtmf	Conference	h	Available for hosts (h) only
Find out how many users are in the queue DTMF binding	call_find_dtmf_binding	Conference	*#	
Instructions DTMF policy	call_instructions_dtmf	Conference	h	Available for hosts (h) only
Instructions DTMF binding	call_instructions_dtmf_binding	Conference	**	
Move user to a conference DTMF policy	call_move2conf_dtmf	Conference	h	Available for hosts (h) only
Move user to a conference DTMF binding	call_move2conf_dtmf_binding	Conference	*5	
Call operator after number of unsuccessful attempts to enter access code	call_operator_after	DNIS	3	
Hear current status DTMF policy	call_status_dtmf	Conference	h	Available for hosts (h) only

Attribute Description	Attribute Name	Role	Default Value	Notes
Hear current status DTMF binding	call_status_dtmf_binding	Conference	*6	
Start or stop surveillance DTMF policy	call_surveillance_dtmf	Conference	h	Available for hosts (h) only
Start or stop surveillance call DTMF binding	call_surveillance_dtmf_binding	Conference	*1	
Receive call DTMF policy.	call_talk_dtmf	Conference	h	Available for hosts (h) only
Receive call DTMF binding.	call_talk_dtmf_binding	Conference	*2	
<u>conference</u>				
Callers database	conference_callerdb	Conference	off	Selected in dropdown list, other value: on
Dilaout DTMF policy	conference_dialout_dtmf	Conference	h	Available for hosts (h) only
Dilaout DTMF binding	conference_dialout_dtmf_binding	DNIS	*7	
Mask dids for operator	conference_dids_mask	Conference	*	
Enter job code DTMF policy	conference_jobcode_dtmf	Conference		
Enter job code DTMF binding	conference_jobcode_dtmf_binding	DNIS		
Language	conference_language	Conference	default	
Music on hold	conference_moh	Conference	default	
Realtime protocol	conference_realtime	Conference	off	Selected in dropdown list, other value: on
<u>dnis</u>				
Authorize method	dnis_authorizemethod	DNIS	local	Selected in dropdown list, other values: free, vssradius, wyderadius, ldap
Billing rule	dnis_billingrule	DNIS	default	
Conference numbers domain	dnis_domain	DNIS	0	
Maximal number of calls per DNIS	dnis_maxcalls	DNIS	-1	
Welcome prompt	dnis_welcomeprompt	DNIS	default	
<u>recording</u>				
Recording server address	recording_addr	DNIS		
Recording method	recording_method	DNIS	local_trusted	Selected in dropdown list, other values: local, remote, remote_trusted

PLAYBACK

The PLAYBACK call is used to playback previously recorder conferences. The user calls to the PLAYBACK call number, then the user enters the conference access code, and after that he is able to playback the conference.

Open DNIS section of the portal by clicking the “DNIS” menu. Then click “PLAYBACK” in lower section (Call Flows) of the screen to edit PLAYBACK call flow attributes. The screen should look similar to Figure 52. Available PLAYBACK call flow attributes are listed in Table 14.

WYDE VOICE

24/7 Professional Customer Service
TOLL FREE 866.508.9020

Subscribers | Conferences | Calls | Reports | **DNIS** | Preferences | Logout | CONFERENCE APPLIANCE MANAGER

*Call Flow Name

*Directory Path

Description	Name ▲	Role	Value
<u>call</u>			
Delay before answer	call_delay	DNIS	<input type="text" value="2"/>
Maximal calls duration	call_maxduration	DNIS	<input type="text" value="-1"/>
<u>dnis</u>			
Authorize method	dnis_authorizemethod	DNIS	<input type="text" value="local"/>
Language	dnis_language	DNIS	<input type="text" value="default"/>
Maximal number of calls per DNIS	dnis_maxcalls	DNIS	<input type="text" value="-1"/>
Referred DNIS number	dnis_number	DNIS	<input type="text" value="10"/>
Welcome prompt	dnis_welcomeprompt	DNIS	<input type="text" value="default"/>

FCC-CA ver. 1.4.41 ws ver. 1.4.40 ©2006-2009 Wyde Voice, All Rights Reserved.

Figure 53: Modifying PLAYBACK Call Flow Attributes

Table 14: PLAYBACK Call Flow Attributes

Attribute Description	Attribute Name	Role	Default Value	Notes
<u>call</u>				
Delay before answer	call_delay	DNIS	2	
Maximal calls duration	call_maxduration	DNIS	-1	
Call operator after number of unsuccessful attempts to enter access code	call_operator_after	DNIS	3	
<u>conference</u>				
Language	conference_language	Conference	default	
<u>dnis</u>				
Authorize method	dnis_authorizemethod	DNIS	local	Selected in dropdown list, other values: free, vsradius, wyderadius, ldap
Billing rule	dnis_billingrule	DNIS	default	
Maximal number of calls per DNIS	dnis_maxcalls	DNIS	-1	
Referred DNIS number	dnis_number	DNIS	10	
Welcome prompt	dnis_welcomeprompt	DNIS	default	

Recording and Playing Back a Conference

The WYDE architecture has the ability to record and playback a conference call. This can be a very valuable tool. It should be noted that only some call flows include recording as an option (typically a custom call flow).

Recording Instructions

During the live conference, the host can start recording at any time by pressing *9. The system disconnects him/her from the free live conference and prompts for the Subscriber PIN. If the Subscriber PIN is valid, the host is returned to the conference and all attendees are notified that the recording option has been started. To stop the recording, the host will press *9 again.

Play Back Instructions

To listen to the recorded conference, the host must provide attendees with the play back number and access code. Please note, this number is different from the conference dial-in number. When users call into the recording playback number, they will be prompted to enter the access code. Once confirmed, the system will play back the recorded conference. During play back, the user can scroll forward or backwards through the recorded conference. You will find the play back features listed in Table 15.

Table 15: Recorded Conference Call Playback Touch Tone Commands

Playback Touch Tone Command	Description
*1	Rewind 30 seconds
*2	Fast forward 30 seconds
*5	Pause/resume playback

SPECTEL

The SPECTEL call is similar to CONF call flow. The difference from CONF call flow is that this one more suitable for more organized conferences where authentication is important; where participants should wait for the host to start a conference or be disconnected after host hangs up. Also, each participant can have their own access code, or the participants can share an access code, or you can give groups of participants their own access codes.

Open DNIS section of the portal by clicking the “DNIS” menu. Then click “SPECTEL” in lower section (Call Flows) of the screen to edit SPECTEL call flow attributes. The screen should look similar to Figure 52. Available SPECTEL call flow attributes are listed in Table 16.

Table 16: SPECTEL Call Flow Attributes

Attribute Description	Attribute Name	Role	Default Value	Notes
<u>call</u>				
Announce participant count on enter	call_announceparticipantcount	Conference	hpl	Available for hosts (h), participants (p), and listeners (l)
Delay before answer	call_delay	DNIS	2	
Exit DTMF policy	call_exit_dtmf	Conference		
Exit DTMF binding	call_exit_dtmf_binding	DNIS		
Gain control decreasing policy	call_gaindec_dtmf	Conference		
Gain control decreasing binding	call_gaindec_dtmf_binding	DNIS		
Gain control increasing policy	call_gaininc_dtmf	Conference		

Attribute Description	Attribute Name	Role	Default Value	Notes
Gain control increasing binding	call_gaininc_dtmf_binding	DNIS		
Instructions DTMF policy	call_instructions_dtmf	Conference	hp	Available for hosts (h) and participants (p)
Instructions DTMF binding	call_instructions_dtmf_binding	DNIS	**	
Enter job code when joins the conference	call_jobcodeonenter	Conference	h	Available for hosts (h) only
Maximal calls duration	call_maxduration	DNIS	-1	
Mute self DTMF policy	call_mute_dtmf	Conference	hp	Available for hosts (h) and participants (p)
Mute self DTMF binding	call_mute_dtmf_binding	DNIS	*6	
Call operator after number of unsuccessful attempts to enter access code	call_operator_after	DNIS	3	
Call for Operator DTMF policy	call_operator_dtmf	Conference		
Call for Operator DTMF binding	call_operator_dtmf_binding	DNIS	*0	
Tell number of participants during the conference DTMF policy	call_participantsnumber_dtmf	Conference	hp	Available for hosts (h) and participants (p)
Tell number of participants during the conference DTMF binding	call_participantsnumber_dtmf_binding	DNIS	*8	
conference				
Application specific data	conference_appspecific	Conference		
Callers database	conference_callerdb	Conference	off	Selected in dropdown list, other value: on
Dilaout DTMF policy	conference_dialout_dtmf	Conference	h	Available for hosts (h) only
Dilaout DTMF binding	conference_dialout_dtmf_binding	DNIS	*1	
Distributed conferencing	conference_distributed	Conference	off	Selected in dropdown list, other value: on
Entry and exit tones DTMF policy	conference_entryexittones_dtmf	Conference		
Entry and exit tones DTMF binding	conference_entryexittones_dtmf_binding	DNIS		
Entry tones	conference_entrytones	Conference	on	Selected in dropdown list, other value: off
Exit tones	conference_exittones	Conference	on	Selected in dropdown list, other value: off
Conference extended menu DTMF policy	conference_extended_dtmf	Conference	hpl	
Conference extended menu DTMF binding	conference_extended_dtmf_binding	Conference	#	
Extra services URIs	conference_extra	Conference		
Hold policy for participant	conference_hold_participant	Conference	false	Selected in dropdown list, other value: true
Enter job code DTMF policy	conference_jobcode_dtmf	Conference	h	Available for hosts (h) only
Enter job code DTMF binding	conference_jobcode_dtmf_binding	DNIS		
Language	conference_language	Conference	default	
Lock conference DTMF policy	conference_lock_dtmf	Conference	h	Available for hosts (h) only
Lock conference DTMF binding	conference_lock_dtmf_binding	DNIS	*7	
Max number of calls per conference	conference_maxcalls	Conference	-1	
Maximal conference duration	conference_maxduration	DNIS	-1	
Music on hold	conference_moh	Conference	default	
Mute mode DTMF policy	conference_mute_dtmf	Conference	h	Available for hosts (h) only
Mute mode DTMF binding	conference_mute_dtmf_binding	DNIS	*5	

Attribute Description	Attribute Name	Role	Default Value	Notes
Mute policy for listener	conference_mute_listener	Conference	strict	Selected in dropdown list, other value: open, relaxed
Get participants count and detailed participants info	conference_participantsinfo_dtmf	Conference		
Get participants count and detailed participants info	conference_participantsinfo_dtmf_binding	DNIS		
Q&A session DTMF policy	conference_qa_dtmf	Conference	h	Available for hosts (h) only
Q&A session DTMF binding	conference_qa_dtmf_binding	DNIS	*3	
Realtime protocol	conference_realtime	Conference	on	Selected in dropdown list, other value: off
Conference roll call default	conference_rollcall	Conference	off	Selected in dropdown list, other value: on
Entry name	conference_rollcall_onenter	Conference	off	Selected in dropdown list, other value: on
Exit name	conference_rollcall_onexit	Conference	off	Selected in dropdown list, other value: on
Conference schedule		Conference		
Schedule conference extend maximal time in seconds	conference_schedule_extend	DNIS	1800	
Schedule conference extend DTMF policy	conference_schedule_extend_dtmf	Conference	h	Available for hosts (h) only
Schedule conference extend DTMF binding	conference_schedule_extend_dtmf_binding	DNIS		
Wait before scheduled conference begin	conference_schedule_hold	DNIS	300	
Schedule conference end remind time in seconds	conference_schedule_remind	DNIS	120	
Conference scheduled	conference_scheduled	Conference	off	Selected in dropdown list, other value: on
How conference begins	conference_start_how	Conference	first	Selected in dropdown list, other value: moderator
Wait to start without moderator	conference_start_wait	Conference	3000	
How conference ends	conference_stop_how	Conference	last	Selected in dropdown list, other value: moderator
Wait before disconnect when moderator left the conference	conference_stop_wait	Conference	0	
<u>dnis</u>				
Authorize method	dnis_authorizemethod	DNIS	local	Selected in dropdown list, other values: free, vsradius, wyderadius, ldap
Billing rule	dnis_billingrule	DNIS	default	
Maximal number of calls per DNIS	dnis_maxcalls	DNIS	-1	
Playback number	dnis_playbacknumber	DNIS		
Validate subscriber pin	dnis_validatesubscriberpin	DNIS	off	Selected in dropdown list, other value: on
Welcome prompt	dnis_welcomeprompt	DNIS	default	
<u>recording</u>				
Recording server address	recording_addr	DNIS		
Recording DTMF policy	recording_dtmf	Conference	h	Available for hosts (h) only
Recording DTMF binding	recording_dtmf_binding	DNIS	*9	
Recording method	recording_method	DNIS	local_trusted	Selected in dropdown list, other values: local, remote, remote_trusted
How recording ends	recording_stop_how	Conference	last	Selected in dropdown list, other value: moderator

Attribute Description	Attribute Name	Role	Default Value	Notes
Wait before stop recording when moderator left the conference	recording_stop_wait	Conference	0	

Sample of Conference Call Procedures Using the SPECTEL Call Flow

This section describes the basic procedures used within a conference call that uses the SPECTEL call flow. These procedures should be familiar to you if you have ever moderated or participated in a conference call. The difference from CONF call flow is that this one more suitable for more organized conferences where authentication is important; where participants should wait for the host to start a conference or be disconnected after host hangs up.

Entering conference call as a Host

The person responsible for managing the conference call while in progress is known as the Host. This person has special functions they can use to facilitate the call. The following is the procedure for entering a conference call:

1. Dial the host number, wait for the welcome prompt.
2. When prompted, enter the assigned access code, followed by the # key.
3. Once connected to the live conference, the host can control the call with the commands given in Table 17.

Table 17: Host Commands for SPECTEL Call Flow Conferences

Touch Tone Command	Description
*1	Dial Out to a 3 rd party
*2	Record a conference
*3	Start Q&A Session
*4	Increase/Decrease volume
*5	Conference lecture mode on/off (Mute all Participants)
*6	Mute Host Line
*7	Lock Conference on/off
*8	Participant count or roll call
**	Listen to Instructions

Entering a conference call as a Participants

To enter a SPECTEL conference call as a participant, the procedure is similar to CONF, bearing in mind that a SPECTEL conference call uses a different set of procedures than CONF call flow calls. Use the following procedure when dialing in to SPECTEL conference calls:

1. Dial the host number, wait for the welcome prompt.
2. When prompted, enter the assigned access code, followed by the # key.
3. Once connected to the live conference, every caller will be able to talk (unless they have been configured as a listener in the call setup). Every caller will also have access to the touch tone commands listed in Table 18.

Table 18: Participant Commands for SPECTEL Call Flow Conferences

Touch Tone Command	Description
*6	Mute Host Line
*8	Participant count or roll call
**	Listen to Instructions

Appendix A: Support Resources

If you have difficulty with this guide and any of the procedures listed herein, please contact us using the following support resources.

Support Documentation

In addition to this Guide, you may obtain other WYDE Voice documentation from WYDE Voice or from the WYDE Voice documentation Web site: <http://docs.wydevoice.com/>.

Web Support

Our support website is available 24 hours a day, 7 days a week, and 365 days a year at <http://www.wydevoice.com>. You may download patches, support documentation and other technical support information.

Telephone Support

For difficulties with any procedures described in this Guide, please contact us at 866-508-9020 during our normal phone support hours of 7:00 am to 6:00 pm Pacific Standard Time (PST). An engineer will respond to your inquiry within 24 hours.

Email Support

You may also email us your questions at support@wydevoice.com. We will respond to your question within 24 hours.